

# Systems

ATR TRAINING & FLIGHT OPERATIONS SERVICES



*Scan your aircraft*

42-500

72-212A

1, allée Pierre Nadot – 31712 Blagnac Cedex – France  
Phone: 33 (0)5 62 21 62 07 – Fax: (0)5 62 21 63 67  
e-mail: [atc@atr.fr](mailto:atc@atr.fr)

An Alenia Aeronautica and EADS joint venture

**ATR**

Edition 2010

An Alenia Aeronautica and EADS joint venture

**ATR**

# Introduction

This Systems guide is an essential tool for all ATR flight crew and engineer to learn or review **ATR systems** operation. To make learning process easier, systems are introduced in a user-friendly and efficient training method, including diagram and schematic display as appropriate.

This guide is a comprehensive document that efficiently complements FCOM 1<sup>st</sup> part – *Systems description*. Systems are organized as per FCOM chapter, including their ATA classification along with cockpit location. Cockpit panels familiarisation is presented with each relevant system description in a separate annex.

This new guide release is intended for training on ATR 42-500 and 72-212A. It presents a generic aircraft not customized to your own aircraft systems. Should you find any discrepancy between Systems guide and your customized ATR operational documentation (AFM, FCOM & QRH), the latter takes precedence.

NB: This Systems guide is also available for ATR 42-300 and 72-200 not PEC. This document will also be developed for the ATR-600.

The Training and Flight Operations support team.

**Chapter A. Aircraft general**

1. Doors location.....	7
2. Cargo door panel.....	8
3. Doors panel.....	8
4. External lights.....	9
5. EXT LT panel.....	10
6. Memo panel.....	10
7. Signs panel.....	10
8. Internal lighting.....	11
9. LT panel.....	12
10. ANN LT panel.....	12
11. Side panel.....	12
12. FLT COMPT LT panel.....	12

**Chapter B. Multi Function Computer..... 13****Chapter C. Centralized Crew Alerting System**

1. Cockpit philosophy.....	16
2. CCAS description.....	17
3. Crew alerting panel.....	18
4. EMER audio cancel & TO Config test.....	19
5. Aural alarms.....	20

**Chapter D. Air**

1. Pneumatic system.....	22
1.1. Schematic.....	22
1.2. AIR BLEED panel.....	23
2. Air conditioning.....	24
2.1. Schematic.....	24
2.2. COMPT TEMP panel.....	25
3. Avionics ventilation.....	26
3.1. Schematic.....	26
3.2. AVIONICS VENT panel.....	26
4. Pressurization.....	27
4.1. Schematic.....	27
4.2. Cabin pressure indicators.....	28
4.3. Auto-press panel.....	28
4.4. MAN RATE Knob & Cabin press panel.....	28

**Chapter E. Automatic Flight Control System**

1. Schematic.....	30
2. ADU.....	31
3. AFCS control panel.....	31

**Chapter F. Communications**

1. Schematic.....	33
2. PTT selector & NOSE WHEEL STEERING CONTROL switch.....	33
3. Audio control panel.....	34
4. VHF.....	34
5. AUDIO SEL pb.....	34
6. Loudspeaker volume knobs.....	34

7. TCAS control box .....	35
8. EMER LOC XMTR panel .....	35
9. Cabin attendant handset .....	35
10. Handmike & handset .....	35
11. CALLS panel .....	35
12. Head set / Boom set / Hand mike panels .....	36
13. ATC box .....	36
14. CVR panel .....	36
15. Crew oxygen mask .....	36

## Chapter G. Electrical Systems

1. Sources of power .....	38
2. DC-AC schematic .....	40
2.1. Normal supply: On ground with battery only .....	40
2.2. Normal Supply: On ground with external power .....	41
2.3. Hotel mode or DC GEN 1 FAULT .....	42
2.4. Normal supply: with two generator on line .....	43
2.5. Emergency supply: In dual DC GEN LOSS with the battery toggle switch on OVRD .....	44
2.6. Emergency supply: In dual DC GEN LOSS with the battery toggle switch on OVRD and second OVRD selected .....	45
2.7. Emergency supply: In dual DC GEN LOSS with TRU .....	46
3. DC-AC panel .....	47
4. ACW schematic .....	48
5. ACW panel .....	49
6. Breakers panels .....	50
6.1. Overhead panel .....	50
6.2. Electric rack behind F/O .....	50

## Chapter H. Emergency equipment

1. Emergency equipment situation .....	52
2. Emergency lighting system .....	52
3. First aid kit .....	53
4. Crash axe .....	53
5. Megaphone .....	53
6. Flashing light .....	53
7. Life jacket .....	53
8. Escape rope .....	53
9. Gloves .....	54
10. Water extinguisher .....	54
11. Halon extinguisher .....	54
12. Oxygen schematic .....	54
13. Oxygen panel .....	55
14. Cockpit crew oxygen mask .....	55
15. Portable oxygen bottle .....	55
16. Passenger oxygen mask .....	55
17. Protective breathing equipment .....	55

## Chapter I. Fire protection

1. Schematic .....	57
2. Avionics FWD & AFT detection .....	57
3. Fire handle .....	58

4. Compartment smoke panel.....	58
5. Condition levers fuel light.....	58

## Chapter J. Flight control

1. Roll schematic.....	60
2. Pitch schematic.....	60
3. Yaw schematic.....	61
4. Gust lock.....	61
5. Stick Shaker/Stick Pusher push button and light.....	61
6. Spoilers position indicator.....	62
7. Pitch trim asym light.....	62
8. Trim position indicator.....	62
9. Trim controls.....	62
10. Flaps schematic.....	63
11. Flaps position indicator.....	63
12. Flaps control lever.....	63

## Chapter K. Flight instruments

1. Schematic.....	65
2. EADI.....	66
3. EHSI.....	66
4. EHSI with composite mode.....	67
5. EHSI - ARC MODE with terrain or weather radar information.....	67
6. Source failure alert.....	67
7. Sources switching panel.....	68
8. EFIS control panel.....	68
9. Weather radar control.....	69
9.1. Primus 800.....	69
9.2. Primus 660.....	69
10. AHRS erect PB.....	69
11. TAT/SAT indicator.....	70
12. Clock.....	70
13. RCDR panel.....	70
14. STBY instruments.....	70
15. Airspeed indicator.....	71
16. Altimeter.....	71
17. RMI.....	71
18. Flight data entry panel.....	72
19. TCAS vertical speed indicator.....	72

## Chapter L. Fuel system

1. Schematic.....	74
2. Starting procedure.....	75
3. Normal procedure.....	76
4. Crossfeed procedure.....	77
5. Engine feed jet pump low pressure.....	78
6. Low level.....	79
7. Engine fire procedure.....	80
8. Fuel panel.....	81
9. Fuel QTY panel.....	81
10. XFEED advisory light.....	81

## Chapter M. Hydraulic

1. Schematic	83
2. HYD PWR panel	83
3. Pressure indicator	83
4. AUX pump pedestal switch	83

## Chapter N. Ice and rain protection

1. Schematic	86
2. Probes and windshield HTG	87
3. Rain protection	87
4. Ice detector & icing AOA	87
5. De-icing schematic	88
6. Anti-icing & de-icing panel	90
7. De-icing (memo panel)	90

## Chapter O. Landing gear

1. Landing gear description	92
2. Brakes schematic	92
3. LDG GEAR position indicators	93
4. Landing gear handles	93
5. Brakes temperature and antiskid	93
6. Emergency parking brake handle	93
7. Steering handwheel	93

## Chapter P. Navigation system

1. Nav control box	95
2. Marker switch	95
3. ADF control box	95
4. EGPWS alert modes	95
5. EGPWS pb	99
6. EGPWS selector	99
7. Global navigation satellite system (GNSS)	100

## Chapter Q. Power plant

1. Engine schematic	102
2. Power and propeller controls	103
3. Engine indicators	106
4. ENG START panel	107
5. ENG control panel	107
6. PWR MGT panel	108
7. ATPCS test panel	108
8. Idle gate	108

## Annexes

Annex 1. Cockpit panels	110
Annex 2. Abbreviations	123

# A. Aircraft general

FCOM 1.00



# 1. Doors location

ATA 52



Cargo door



Emergency exit type III



Service door / emergency exit type I



Pilot emergency hatch



Pilot communication hatch

Rear entry door / emergency exit type I




Aft avionics compartment door

Forward avionics access hatch



## 2. Cargo door panel



ATA 52

### ARMED light

-Selector armed green light is ON, when actuator selection switch working conditions are met:  
 -cover panel opened  
 -door unlocked by operating handle: all hooks are disengaged and FWD latchlock is unfastened

### LCHD light

blue light is ON when all door hooks and latch locks are fully engaged

### GND HDL light

Ground handling bus ON BAT red light is On when ground handling bus is directly supplied by HOT main bat bus: means that the battery is discharging even if the BAT toggle switch is in OFF position (visible even when the cover panel is closed)  
 This red light is ON when:  
 - The refueling panel is open  
 - The cargo door control panel is open  
 - The passenger door is open and alert, that the battery is discharging before leaving the aircraft



### Actuator selection switch

is used to operate the door (**OPEN** or **CLOSE**) when the CARGO DOOR ARMED green light is on

### Panel cover switch

connects the ground handling bus on line when the panel cover is opened and allows operation of cargo door. During the opening, a self test of the MFC 1A and 2A is performed to initiate the control system of the cargo door.

### CARGO LIGHT switch

allows activation of the cargo bay light from outside

## 3. Doors panel



ATA 33

### DOORS lights


**CABIN** and **CARGO** aural alarms are inhibited when the Condition Lever 1 is on FTR or FUEL SO  
**SVCE** and **FWD COMPT** aural alarms are inhibited when the Condition Lever 2 is on FTR or FUEL SO

### CAB OK and SVCE OK

Light on when SW TEST depressed and check microswitches operation

### SW TEST

Tests continuity of microswitch system (on ground, doors opened)




### UNLK


At least 1 micro switch is opened

# 4. External lights

ATA 33



- A - Navigation lights
- B - Taxi and T/O lights
- C - Landing lights
- D - Wing lights
- E - Beacon lights
- F - Strobe lights
- G - Logo lights
- H - Emergency light




## 5. EXT LT panel



ATA 33

**BEACON and NAV**  
supplied by SVCE BUS and BUS 1  
**LOGO**  
supplied by SVCE BUS

**TAXI & T.O**  
Supplied by ACW BUS 2



**STROBE, LAND**  
supplied by ACW BUS 1 (Left Hand), ACW BUS 2 (Right Hand)

**WING**  
Supplied by DC BUS 2

## 6. MEMO panel




ATA 33

**SEAT BELTS**  
illuminates blue when associated switch is selected ON



**NO SMKG**  
illuminates blue when associated switch is selected ON

## 7. Signs panel



ATA 33

**NO SMKG and SEAT BELTS**  
Blues Lts on MEMO panel when ON. (DC BUS 2)






**ON**  
emergency exit lights illuminates.  
Supply: DC STBY or 6 V BAT packs

**ARM**  
Emergency lights illuminate when <18 V on STBY bus or if both DC GEN off line. Emergency lights extinguish when >20V on STBY bus and at least 1 GEN operating


**DISARM**  
system deactivated

# 8. Internal lighting

ATA 33



## 9. LT panel




ATA 33

### INST

Selects activation and intensity of main panel instrument integral lighting

### DSPL knob

selects activation and intensity of all digit lighting



### PNL rotary selector


selects activation and intensity of glareshield, pedestal and overhead panels instrument integral lighting




### FLOOD knob

selects activation and intensity of pedestal panel flood lighting. (OFF TO BRT)

## 10. ANN LT panel



ATA 33



To check and control the intensity of:

- the annunciator lights on the overhead and pedestal panels
- the overhead panel flow bars

**TEST:** All the associated lights come on bright

**BRT:** associated light illuminate bright

**DIM:** associated light are dimmed

## 11. Side panel



ATA 33

### CAPT CONSOLE LT knob


selects activation and intensity of the respective lateral console



### CAPT READING LT knob

selects activation and intensity of the respective spot light

## 12. FLT COMPT LT panel



ATA 33

### DOME switch

**BRT:** dome lights are supplied with maximum intensity

**DIM:** dome lights are dimmed

**OFF:** both dome are off

**DOME light:** the F/O dome light becomes BRT when the switch in BRT or DIM if:

- dual DC GEN loss
- or on ground, with BAT supply only



### STORM switch

On position, flood lights are ON with maximum intensity and fluorescent tubes are ON

### STBY COMPASS switch

to illuminate the STBY COMPASS **ON** and **OFF** position

# B. Multi Function Computer

FCOM 1.01




## B. Multi Function Computer

Numerous logic functions are performed by two independent computers (MFC1 and MFC2). Each computer includes two independent modules (A and B)

The purpose of these computers is to:

- monitor, control, authorise operation of the aircraft systems
- manage system failures and flight envelope anomalies and command triggering of associated warning



**OFF**  
The module stops operating

### FAULT

illuminates and the CCAS is activated when a malfunction or electrical supply fault is detected. The module automatically becomes inoperative. This light also flashes during self-test of the module.

During powering, since all 4 modules are selected ON, the following sequence is executed:

MFC 1A and MFC 2A FAULT lights flashing (self-test of these modules)

MFC 1A and MFC 2A FAULT lights extinguish.

MFC 1B and MFC 2B FAULT lights flashing (self-test of these modules)

MFC 1B and MFC 2B FAULT lights extinguish

**NOTE:** Here, if the cargo door control panel is opened, the self test of MFC 1A and 2A are already done, and only the MFC 1B and 2B are tested. (See chapter A.2)

- The MFC functions can be treated:
- in one module only
  - in several modules (redundancy)
  - partially in 2 modules

### Example:

SYSTEM	FUNCTION	MODULE			
		1A	1B	2A	2B
FLIGHT	STICK PUSHER	◐	◐	◑	◑
CONTROLS	STALL WARNING		●		●

- The stick pusher function is integrated in modules 1A, 1B, 2A and 2B.
- The stall warning function is integrated in modules 1B and 2B.
- The stick pusher function is available if modules (1A AND 2A) OR (1A AND 2B) OR (1B AND 2A) OR (1B AND 2B) operate. This function is therefore not available if modules (1A AND 1B) OR (2A AND 2B) are lost.
- The stall warning is available if modules 1B OR 2B operate. This function is therefore not available if modules 1B AND 2B are lost.

# C. Centralized crew alerting system


FCOM 1.02



## 1. Cockpit philosophy

ATA 31

In normal operation, all the lights are extinguished (Dark cockpit philosophy). With few exceptions, the lights illuminate to indicate a failure or an abnormal condition.

	Normal operation
	Warning indication
	Caution indication
	Other than normal basic operation
	Temporarily required system in normal operation
	Back up or alternate system selected

## 2. CCAS description

## ATA 31

The CCAS draws crew's attention when a failure is detected and guides the crew to the system affected by the failure

- Three types of visual devices are used:
- MASTER WARNING and MASTER CAUTION lights
  - CREW ALERTING PANEL (CAP) lights
  - LOCAL ALERT lights


### Detection sequence

INFORMATION

IDENTIFICATION

ISOLATION


**Example:** ACW Generator 1 failure




## 3. Crew alerting panel



ATA 31





## 4. EMER audio cancel & TO config test



ATA 31

**EMER AUDIO CANCEL**  
Guarded switch, cancel the aural specific of an undue continuous aural except for landing gear, VMO, VFE, VLE, stall warning, pitch trim whooler, landing gear, AP disconnection



**TO CONFIG TEST**  
- To check T/O configuration (PWR MGT in T/O+ TLU LO SPD illuminated + pitch trim in green sector+flaps 15° + ail lock light extinguished) by simulating power levers at T/O position, except PARK BRAKE  
- To perform an automatic RECALL

## 5. Aural alarms

ATA 31



### CLACKER

$V_{MO}$   
 $V_{LO} - 5 \text{ kt}$   
 $V_{FE} - 5 \text{ kt}$

### DOOR BELL

Hostess or  
ground calls

### WHOLLER

Pitch trim in motion  
(more than 1s)

### CAVALRY CHARGE


AP Disconnects

### C CHORD

Altitude alerts

### CRICKET

Stall warning associated  
STICK SHAKER/PUSHER  
AOA (Angle Of Attack)



# D. Air

FCOM 1.03




## 1. Pneumatic system

ATA 21/36

The pneumatic system supplies aircraft systems which use pressurized air:

- These systems are:
- Air conditioning
  - Ventilation
  - Pressurization
  - De-icing

### 1.1. Schematic



## 1.2. AIR BLEED panel



### ENG BLEED

Controls both bleed and HP valves. Spring loaded closed. Must have air and electricity to open  
Auto closure when OVHT, leak, overpressure, fire T pulled, when UPTRIM is triggered or prop break on (left one only). Inhibited during eng start

### GRD X FEED


Spring loaded closed. Ground only inhibited in flight. Auto opens when only one bleed valve is opened

### PACK VALVE

Spring loaded closed. Must have air and elect power to open. 6" delay on RH valve for pax comfort

### OVHT

either duct temp switch above 274°C. CAP. Auto closure bleed valves (LP and HP). May be reset after cooling



### PACK VALVE FAULT

pack valve disagreement with pb / or OVHT downstream pack comp. (>204°C). CAP. Valve auto closed. Ground cooling turbo fan failure

### ENG BLEED

**FAULT**  
Bleed valve disagreement with selected position (or in case of **OVHT** or **LEAK**). CAP. Associated valves auto closed

### LEAK


activates when T° detected by bleed loop exceeds 153 ±8°C. CAP. Auto closure after 1" of following valves: Bleed, HP, pack and GND Xfeed if left bleed leak affected  
**DO NOT RESET BLEED**

## 2. Air conditioning

ATA 21

The air conditioning system is provided to keep the flight compartments to the required temperature, pressure, humidity and cleanliness for the comfort of the passengers and crew.

### 2.1. Schematic



Cooling of air:

- by two ground turbo fans:
  - IAS ≤ 150 kt and ldg gear is retracted for less than 10 min
  - IAS ≤ 150 kt and ldg gear is extended.
- by ram air when IAS > 150 kt

## 2.2. COMPT TEMP panel



**RECIRC FAN**  
Assists pack air flow

**COMPT INDICATOR**  
Duct temperature limited to 88°C. (191°F) by pneumatic temp.limiter

**TEMP SEL**  
**OVHT:** duct overheat > 92 °C + **AIR** on CAP. Pack valve will not auto close

**MAN**  
compt temp knob controls directly temp control valve

**RECIRC FAN**  
**FAULT:** fan low speed or motor overheat + **AIR** on CAP. No auto disconnect

**TEMP SEL**  
AUTO: the temperature is closed by the electronic temperature controller, taking into account:  
- duct temperature  
- zone temperature demand selector  
- associated compartment temperature  
- aircraft skin temperature

**FLOW**  
**NORM:** 22 psi (pack valves)  
**HIGH:** 30 psi (pack valves)

**Panel Labels:** EXHAUST MODE, AVIONICS VENT, OVBD VALVE, RECIRC FAN 1, COMPT TEMP, RECIRC FAN 2, TEMP SEL, COMPT SEL, PACK VALVE, AIR BLEED, ENG 1 BLEED, ENG 2 BLEED, ENG/WING DE ICING, COLD, HOT, AUTO, MAN, OFF, FAULT, OVBD, OVHT, LEAK, X VALVE OPEN, GRD X FEED, NORM, HIGH, FLOW, CABIN, FLT COMPT, DUCT °C, 0, 15, 20, 25, 30, 50, 100.

**CAUTION:** DO NOT SEL OVBD VALVE FULL OPEN IF ΔP > 1PSI

**OVBD VALVE:** FULL OPEN, AUTO, FULL CLOSE

**TEMP SEL:** AUTO, OVHT, MAN

**COMPT SEL:** COMPT, CABIN

**PACK VALVE:** FAULT, OFF

**ENG BLEED:** OVHT, FAULT, OFF, LEAK

**AIR BLEED:** X VALVE OPEN


**FLOW:** NORM, HIGH

## 3. Avionics ventilation

ATA 21

The ventilation system provides cooling through ambient air extraction to limit the internal operating temperature of the electronic equipment

### 3.1. Schematic



### 3.2. AVIONICS VENT panel



**EXHAUST MODE**  
**NORM**

- On ground, ENG 1 off: extract fan on. OVBD valve full open, U/F valve closed
- Air/ground, ENG 1 on: extract fan operates. OVBD valve closed. U/F valve opened

**FAULT**

fan failure/overheat (fan inhibited for 120 s. after eng start or after a GPU power on. **AIR** on CAP)

**OVBD**

extract fan off  
OVBD valve partially opened (in flight only). U/F valve closed

**FAULT**

OVBD valve in disagreement with ovbd valve SW position

**OVBD VALVE**

- AUTO except for emergency
- direct control of OVBD valve. The full open position is possible only if the delta P is <1 psi

**AVIONICS VENT**

EXHAUST MODE: NORM, FAULT, OVBD

CAUTION: DO NOT SEL OVBD VALVE FULL OPEN IF ΔP > 1PSI



OVBD VALVE: FULL OPEN, AUTO, FULL CLOSE

# 4. Pressurization


# ATA 21

Compressed air is delivered by the packs. Pressure is controlled by the amount of cabin air discharged outboard.

## 4.1. Schematic




## 4.2. Cabin pressure indicators



**ALT**  
Cabin alt: based on 29.92 in.hg  
(1013,2 Hpa)


**DIFF**  
Differential pressure: max  
+6.35/-0.5



**FLAG**  
OFF flag

**RATE**  
Cabin rate of climb

## 4.3. AUTO PRESS panel



**AUTO PRESS** (DC BUS)  
Memorize departure field elevation  
up to 3500 ft

**DUMP**  
FUNCTION ON  
(guarded pusbutton)  
Both outflow valves fully open in  
auto mode only.




**ELV SET**  
Trigger switch to set landing  
elevation

**DESCENT RATE**  
**NORM** = -400 ft/min  
**FAST** = -500 ft/min  
Fast is used when  $V_s > -1500$  ft/  
min

**TEST**  
Displays alternately 18800 and  
-8800, FAULT appears on MAN pb.  
Test is inhibited in flight


## 4.4. MAN RATE KNOB and CABIN PRESS panel



**NORM**  
AUTO MODE position. When used  
in MAN mode, cabin rate selection  
+2500/-1500 fpm

**FAULT**  
digital controller failure. CAP +  
AIR on CAP

**DITCH**  
pb **ON** both outflows are fully  
closed



**MAN**  
digital controller out of operation.  
(no more digits in landing elevation  
display)


# E. Automatic flight control system

FCOM 1.04



## 1. Schematic


ATA 22




## 2. ADU




## ATA 22



## 3. AFCS control panel



## ATA 22



# F. Communications

FCOM 1.05




# 1. Schematic

ATA 23


The communication system provides communication between:

- aircraft and ground stations
- cockpit crew stations
- cabin attendant station
- ground crew stations



# 2. PTT selector and NOSE WHEEL STEERING CONTROL SW

ATA23



**PTT selector**

interphone: forward position  
neutral: center position  
radio: backward position



**NOSE WHEEL STEERING CONTROL switch**

When depressed, BOOM SET or OXY mike is connected for transmission



## 3. Audio control panel



ATA 23

### Transmission keys

Only one key can be engaged at a time. It illuminates white when selected

### VOICE ONLY key

When depressed, it inhibits NAV receivers station identification. Light illuminates amber when selected.

### Volume control knob


to receive volume from associated communication or navigation facilities



### INT/RAD selector

Provides selection of transmission mode when using OXY MASK or BOOM SET mike  
 INT: hot mike position. Interphone is always operative between crew stations. Other transmissions require to select a transmission key and use a PTT pb  
 NEUTRAL: only handmike is usable as long as one transmission key is selected  
 RAD: This position is required to automatically connect for transmissions BOOM SET and OXY MASK mikes without using a PTT pb

## 4. VHF



ATA 23

### ON/OFF switch

energizes the control box and the associated VHF. When pulled, allows override of the automatic squelch

### STO button

allows entering six frequencies in the memory. When depressed, the upper window displays the channel number of available memory (CH1 to CH6)

### TEST button

is used to initiate the radio self-test diagnostic routine



### XFR/MEM switch

This is a three positions spring loaded toggle switch  
 - NEUTRAL  
 - XFR: exchanges preset and active frequency.  
 - MEM: successive actions cycle the six memory frequencies through the display

### ACT button

When depressed, second line displays dashes, and first line can directly be turned for frequency selection

## 5. AUDIO SEL pb



ATA 23

### FAULT

illuminates amber and the CCAS is activated when an associated RCAU processing board failure or power loss is detected



### AUDIO SEL

Controls functioning of associated RCAU processing board.  
 NORM: RCAU functions normally

### ALTN

affected crew station is connected directly to VHF 1 for CAPT station or VHF 2 for F/O station.  
 Volume is adjusted by affected loudspeaker volume control

## 6. Loudspeaker volume knobs



ATA 23



### LOUDSPEAKER

Communication reception.  
 In case of aural alert:  
 - normal volume is always available regardless of knobs position.  
 - during any transmission the volume of both loudspeakers is muted

## 7. TCAS control box

ATA 34



### TCAS rotary selector

**STBY:** TCAS system is under power but intruder visualisation, traffic advisory mode or resolution advisory are not operative  
**AUTO:** normal operating mode of TCAS  
**TA ONLY:** disables the RA mode of operation




### TEST

TCAS test function operates the test during cockpit preparation. Using in flight, TCAS operation are inhibited for up to 20"

## 8. EMER LOC XMTR panel

ATA 23



### AUTO TEST RST

is used in case of undue alert or to test the emergency beacon. two cases are possible for the test  
 - net work X MIT ALERT illuminates amber during 2"  
 - failure XMIT ALERT It flashes during 15 seconds



### Switch

**AUTO** transmission is made automatically at least on 121.5 MHz, 243 MHz and 406 MHz when deceleration exceeds 5 g  
**MAN** allows commanded operation or test

## 9. Cabin attendant handset

ATA 23



### Cabin attendant handset

PA: public adress to make an announcement to passengers  
 INT: internal communications with crew  
 EMER: emergency call


## 10. Handmike and handset

ATA 23




## 11. CALLS panel

ATA 23



### EMER


illuminates in case of emergency call from cabin



### CALLS

**ATTND** to call cabin from cockpit.  
 One time for a normal call  
 three times for an emergency call  
**MECH** to call the ground crew from cockpit  
 A horn is generated  
 In case of cabin crew or ground crew call, depress RESET to cancel both associated visual and aural alerts

## 12. Head set/boom set/ hand mike panels



ATA 23

**Head set / boom set panel / hand mike panels**  
allows connection of a boom set, a head set and a hand mike



## 13. ATC box



ATA 23

**IDENT button**  
when depressed, causes the transponder to transmit IDENT signal


**Power and mode switch**  
**OFF:** control box and receiver are deenergized  
**STBY:** system is under power but does not transmit replies  
**ON:** transponder replies to both mode A and mode C interrogations but without flight level information  
**ALT** normal operating position. Transponder replies with flight level information



**PRE button**  
Push and hold the PRE button allow to select a preset code for storage  
The storage code can be recalled by momentarily pressing the PRE button again

**TEST button**  
initiates the radio self test routine


## 14. CVR panel



ATA 23

**COCKPIT VOICE RECORDER**  
Monitor indicator for test only. Movement of pointer in white band indicates all channels are operative

**HEADSET jack**  
when headset is plugged into the jack:  
- cockpit sounds picked up by the microphone are audible  
- erase tone is audible when ERASE pb is depressed



**TEST pb**  
when depressed and held, the test circuit is activated  
- the pointer moves to a location between graduations 8 and 10  
- if a headset is plugged into the jack, the 600 HZ signal is heard

**ERASE pb**  
provides fast erasure of tape recordings when the landing gear shock absorbers are compressed and parking brake is set (depress for 2 sec. to completely erase)  
During erasure, a 400Hz audio signal can be heard in the headset

**B - MICROPHONE**  
picks up cockpit conversations and alert sounds



## 15. Crew oxygen mask



ATA 23

A micro is incorporated inside the crew oxygen mask



# G. Electrical systems



FCOM 1.06



## 1. Sources of power

ATA 24

Three kind of current are available: Direct current (DC)  
 Alternating current with constant frequency (AC)  
 Alternating current with variable frequency (ACW)




The TRU provides power to the emergency loads in case of dual DC generators loss. It is supplied by the ACW bus 2.


The DC Starter Generator is driven by the HP spool through the Accessory Gear Box (AGB)

- From 0 to 45% NH as a Starter
- Above 61.5% as a Generator

The ACW Generator is driven by the Reduction Gear Box, and is available with NP > 66%



In Hotel Mode or with the propeller feathered, there is no ACW.  
 When the propeller is unfeathered (CL in AUTO), The NP is maintained at a minimum of 70,8%, in order to have ACW (minimum 66%)




HOTEL MODE OR PROPELLER FEATHERED

## 2. DC-AC schematic

ATA 24

### 2.1. Normal supply: On ground with battery only



The **GND HDLG BUS** is supplied only on ground, in three different ways:


- BAT OFF or BAT ON with the EXT PWR not available, the GND HDLG BUS is supplied by the HOT MAIN BAT BUS for ground servicing only when:

- The refueling panel is open
- The cargo door control panel is open
- The passenger door is open


- BAT OFF or BAT ON with the EXT PWR available but not ON, the GND HDLG BUS is supplied directly from the EXT PWR

- BAT ON with EXT PWR ON or with one GEN on line, the GND HDLG BUS is supplied by the DC SVCE BUS.

**NOTE:** The GND HDLG BUS is disconnected when airborne.




## 2.2. Normal Supply: On ground with external power



The BTC is closed and the GPU supplied all the DC and AC busses.  
Even if the GEN are available, the GPU has always the priority




## 2.3. Hotel mode or DC GEN 1 FAULT





The BTC is closed and the GEN 2 supplied all the DC and AC busses.

In hotel mode the GND HDLG BUS is supplied by the DC BUS 1 through the DC SVCE BUS.




### 2.4. Normal supply: with two generators on line




The BTC is opened and each GEN supply its own busses. On ground the GND HDLG BUS is supplied by the DC BUS 1 through the DC SVCE BUS, and disconnected when airborne.


## 2.5. Emergency supply: In dual DC GEN LOSS with the battery toggle switch on OVRD




The BAT toggle switch has to be selected to OVRD. The OVRD position allows to be sure that busses are supplied by their respective battery by overriding all protections. This position is protected by a guard.




## 2.6. Emergency supply: In dual DC GEN LOSS with the battery toggle switch on OVRD and second OVRD selected




After a Dual DC GEN loss, the UNDV is triggered when the DC STBY BUS <19,5 V. Then, by pushing on the OVRD the DC and AC STBY BUS are transferred from the HOT MAIN BAT BUS to the HOT EMER BAT BUS



## 2.7. Emergency supply: In dual DC GEN LOSS with TRU





The TRU connected to the ACW BUS 2 supplies DC EMER BUS, DC ESS BUS, DC&AC STBY BUSES



### 3. DC-AC panel

ATA 24



**UNDV**  
DC STBY < 19.5 V. (No CAP)

**BUS OFF**  
Associated bus deenergized.  
**ELEC** on CAP

**OVRD**  
Xfer/stby busses from HOT MAIN to HOT EMER BAT BUS

**Arrows**  
Emergency supply indicators (respective battery discharging)

**TRU**  
ON PB in. TRU is connected to ACW BUS 2. Arrow illuminates amber when DC EMER, DC STBY, INV 1, AC STBY and DC ESS BUS are supplied by TRU

**EMER BAT CHG**  
**FAULT:** Overheat detected by MFC or failure of contactor. **ELEC** on CAP  
Contactor auto opens if: thermal runaway/bus voltage <25 V. Start sequence: Bat sw on OVRD

**DC BUS OFF**  
Respective bus not supplied.  
**ELEC** on CAP

**DC SVCE/UTLY BUS**  
In automatic shedding One of the DC SVCE/UTLY 1 and 2 busses is shed 1 bus **SHED** (BCPU). **ELEC** on CAP.  
In OFF all DC SVCE/UTLY 1 and 2 busses are shed  
DC SVCE supplies power in flight and on ground during airplane servicing operations.  
UTLY BUSSES supply non-essential loads

**DC GEN 1**  
Generator **FAULT** Lt.  
Extinguishes above 61.5% NH if GEN is operating normally

**INV FAULT**  
Under/over voltage at INV output. (INV failure or supply loss). Auto-Xfer of all AC busses to remaining inverter. **ELEC** on CAP

**OVRD**  
Insures basic mode operation by overriding all other protections

**ON**  
Basic mode: STBY busses supplied by HOT MAIN BAT BUS. Ext or gen power: DC STBY bus transferred to HOT EMER BAT BUS AC STBY BUS to DC BUS 1

**OFF**  
ESS BUS, DC STBY BUS + INV 1 are isolated from HOT MAIN BAT BUS  
DC EMER BUS is isolated from HOT EMER BAT BUS

**BTC**  
Allows BPCU to control BTC operation. Ext power, hotel mode or single gen operation, BTC is closed (green flow bar)

**ISOL**  
BTC and BTR opened (released out)

**DC GEN 2**  
**FAULT:** protection trip by GCU; Auto reset if underspeed: in other cases manual. BTC auto closes


**AVAIL**  
GPU has been checked by BPCU for over/under voltage, over current and polarity

**X START FAIL**  
Opposite generator has not come on line to assist start at 10 % NH

**EXT PWR**  
**AVAIL + ON:** GPU has priority on both generators


## 4. ACW schematic

ATA 24



### ACW supplied by the External Power

- When the ACW GPU is available (**AVAIL**) but not ON, the GPU supplies only the ACW Service Bus, if the GND Service Bus switch, on the flight attendant panel, is ON.
- When the ACW GPU is **ON**, the GPU supplies through the BTC, the ACW BUS 1, the ACW BUS 2 and the ACW SVCE BUS.
- Even if one ACW generator is available, the GPU has always the priority.




### ACW in Hotel mode or with the propeller feathered

**NOTE:** An ACW Generator is available if the NP is above 66%.

- When the right engine is running in hotel mode, the NP=0.
- When the engines are running but the propeller is feathered, the NP is below 20%

In both cases the ACW Busses are not supplied





### The propeller unfeathered and one ACW GEN on line

On ground, when the propeller is unfeathered, the engine is running on fuel governing mode.

The fuel governing mode, maintain a minimum NP of 70.8%, in order to have the ACW available (ACW GEN on line at 66%)


The ACW GEN supplies, the ACW BUS 2 and ACW BUS 1 through the BTC, but the SVCE BUS is shed (one generator is not able to supply all the busses)

**CAUTION:** on ground in case of an EEC or PEC fault, the fuel governing mode is lost and the ACW generator is not available (NP<66%)



**Normal condition in flight**

- The ACW GEN 1 supplies the ACW BUS 1 and the ACW SVCE BUS
- The ACW GEN 2 supplies the ACW BUS 2.
- The TRU is connected to the ACW BUS 2



**One Generator Fault**

When one generator is fault, the other one supplies the ACW BUS1 and the ACW BUS 2 through the BTC.  
The SVCE BUS is automatically shed (one generator is not able to supply all the busses)



**5. ACW panel**



**ATA 24**

**ACW BUS OFF**  
Associated bus not supplied

**BTC** (green flow bar)  
Auto closure when either ACW GEN drops off line

**ACW GEN 1 / 2**  
**FAULT**: Auto reset in case of under/over speed: manual reset otherwise.  
ACW SVCE BUS auto shed if 1 GEN is out

**EXT PWR**  
**AVAIL** + **ON** GPU has priority on both GEN


**ACW GEN 2 and ACW GEN 1**  
Min NP for ACW = 66 %.  
The fuel governing mode maintains a MIN NP of 70.8% to be always above 66%.  
The fuel governing mode is cancelled with the propeller feathered (No ACW)

## 6. Breaker panels



ATA 24

### 6.1. Overhead panel



### 6.2. Electric rack behind F/O




# H. Emergency equipment

FCOM 1.07




The aircraft is equipped with fire fighting, oxygen, first aid equipment and emergency lightning.

## 1. Emergency equipment situation



## 2. Emergency lighting system

ATA 33



### 3. First aid kit

**ATA 25**



contains bandages, burn dressings, small adhesive dressings, antiseptic wound cleaner, adhesive wound closures, disposable resuscitation aid, wound dressings, large and small, adhesive tape, safety pins and scissors, simple analgesic, antiemetic, nasal decongestant, first-aid handbook, splints, suitable for upper and lower limbs, gastro-intestinal antacid, anti-diarrhoeal medication, disposable gloves

### 4. Crash axe

**ATA 25**



Crash axe with pick and edge  
Handle insulated up to 2000V to open a door or a compartment

### 5. Megaphone

**ATA 25**



megaphone 72 only

### 6. Flashing light

**ATA 25**



With batteries, morse code switch

### 7. Life jacket

**ATA 25**



With oral inflation tube, CO2 sparklets, inflation red toggle, whistle, straps, battery, light

### 8. Escape rope

**ATA 25**



used to evacuate the cockpit

## 9. Gloves

ATA 25



To protect against fire

## 10. Water extinguisher

ATA 26



Water extinguisher  
2 liters of water with an anti-ice additive  
discharge time: 30 to 40 "

## 11. Halon extinguisher


ATA 26



Halon extinguisher  
1.2 kg of halon gas  
discharge time: 8 to 10 "

## 12. Oxygen schematic

ATA 35




### 13. Oxygen panel



ATA 35

- MAIN SUPPLY**  
pb in: crew supply only
- HP INDICATOR**  
oxygen bottle pressure.  
Red arc 0 to 85 psi  
Green arc 85 to 2025 psi  
If below 1400 psi, use table




- PAX SUPPLY**  
**ON** 25% for 42-500/72-212A
- LO PR**  
supply below 50 psi

### 14. Cockpit crew oxygen mask



ATA 35

- PRESS TO TEST AND RESET**  
permits a test of oxygen flow without removing the mask from the container. It is springloaded to the reset position
- N/100% PUSH**  
rocker controls the selection of normal or 100% oxygen for mask delivery. It is locked in the 100% position by the unlock rocker
- EMERGENCY**  
selector activates pressurization of mask delivery flow when N/100% rocker is at 100%



- BLINKER**  
displays a yellow cross when there is oxygen flow and black when there is none.
- OXYGEN MASKS**  
quick donning inflatable harness type release clips: squeezing them to unlock the container doors

### 15. Portable oxygen bottle

ATA 35



- Portable oxygen bottle (green) with pressure gauge and re-charge valve  
120 liters under pressure (1800 psi)  
duration: 30 min at 4 ltr/mn  
- 1 bottle -> 42-500  
- 2 bottles -> 72-212A

### 16. Passenger oxygen mask

ATA 35



- 12 Oxygen masks for 42-500  
-19 Oxygen masks for 72-212A equipped with valves, bag and elastic strap

### 17. Protective breathing equipment

ATA 26


- Protective breathing equipment (PBE)**  
to supply 15 min pure oxygen with hood, visor, speaking diaphragm and oronasal mask  
- 2 PBE -> 42-500  
- 3 PBE -> 72-212A



- PBE**  
stowage box

# I. Fire protection


FCOM 1.08



The fire protection system provides detection, warning and extinguishing for each engine, cabin and lavatory.


# 1. Schematic

ATA 35



# 2. Avionics FWD and AFT smoke detection

ATA 35



## 3. Fire handle



ATA 35

### SQUIB TEST

Electrical test of the squibs

### LOOP


**FAULT:** change in resistance, inhibits fire signal until turned off. Loop on CAP (DC emer)

### ENGINE FIRE HANDLE

Pulled on the respective engine:  
 – PROP: feather  
 – FUEL: LP valve closed  
 – AIR: BLEED and HP valve closed  
 – DEICING: deice and shutoff valve closed  
 – ELEC : DC and ACW gen. disconnected  
 – SQUIBS armed Its illumination + Hydraulic to prop brake closed on engine 2

### AGENT 1

**DISCH:** Bottle depressurized. Opposite agent DISCH light will also illuminate on other fire panel. Bottle located in the wing fairing of the associated side



Agent 2 bottle located on the opposite side

### FIRE TEST

MW + CRC + ENG 1 FIRE on CAP + fire handle illuminated + FUEL S/O light on CL (if out of FUEL S/O position)

### AGENT SQUIB

armed when T handle pulled. Discharges bottle. (DC EMER/HOT MAIN BAT)


### FAULT TEST

MC + SC + LOOP on CAP  
 Fault lights in A/B loop pb

### OFF

takes respective loop out of parallel circuit. Allows other loop to activate fire signal alone.

## 4. Compartment smoke panel



ATA 35

### SMK TEST


Tests the smoke detectors working



### NORM

one fan runs  
**FAULT:** the fan is out of order and illuminates amber + CCAS is activated  
**ALTN:** The alternate fan runs, ALTN light illuminates white

## 5. Condition levers fuel light



ATA 35

### FUEL SO

Illuminates red in case of fire signal from associated engine. Extinguishes after CL is set at fuel shut off position or if fire detection signal stops




# J. Flight control

FCOM 1.09




The elevators, ailerons and rudder are mechanically actuated


The spoilers and flaps are hydraulically actuated.



## 1. Roll schematic




## 2. Pitch schematic



In case of jamming, pitch control will be recovered by disengaging the pitch coupling system (by applying a differential force of 52 daN).

### 3. Yaw schematic

ATA 27



### 4. Gust lock

ATA 27




**AIL LOCK**

**GUST LOCK lever**  
permits to lock mechanically the roll and pitch axes against the wing gusts. The PL travel is limited to slightly above FI.


For aircraft equipped with a spring tab on the aileron, the roll locking system is composed of two electro-mechanical locking devices.  
The AIL LOCK is triggered whenever one of the locking actuators is in disagreement with the gust lock position (lock or unlock position)

### 5. Stick Shaker/Stick Pusher push button and light

ATA 27



**STICK SHAKER/PUSHER PB**  
- **FAULT** light indicates a stick pusher or stick shaker failure  
- OFF position: enables to switch OFF the stick pusher and the stick shaker system



**PITCH PUSHER**  
illuminates to indicate that the stick pusher is operating

## 6. Spoilers position indicator



ATA 27



### SPOILERS position indicator

When illuminated, each blue light indicates that the associated spoiler is not in the fully retracted position (more than 2.5° aileron travel)

## 7. Pitch trim asym light



ATA 27




### PITCH TRIM ASYM

light illuminates to indicate a pitch tabs desynchronization greater than 0.7°

## 8. Trim position indicator



ATA 27



### Pitch trim position

indicates the right trim actuator controlled tab travel. A green sector identifies the take off range. If take off (or take off config test) is performed with pitch trim out of this range, CONFIG warning will be generated by the CCAS.

### Roll trim position

indicates the LH aileron trim controlled tab travel

### Yaw trim position

indicates units of trim motor displacement


## 9. Trim controls

ATA 27



### Yaw TRIM control switches

controls the yaw trim actuator. As a safety device both levers must be moved and held in the same direction (nose LH or nose RH) to energize the system and trim the aircraft. When used, the RCU is declutched



### Roll TRIM control SW

controls the roll trim actuator. For operation, both sws must be moved and held in the same direction (L WING DN or R WING DN) to energize the system (safety reasons). The roll trim is inhibited during autopilot operation. When the autopilot is engaged, the "RETRIM ROLL R(L) WING DOWN" message can be triggered on the ADU. This message authorizes to retrim on the dedicated side. the other side is still inhibited

### STBY PITCH control SW

is a guarded sw which controls the electrical motors of each trim actuator. Action on this switch will disengage the autopilot.




### Pitch trim rocker

two switches installed on each control wheel. It is necessary to operate both rocker switches to activate the normal electrical motor of each trim actuator and to control nose up or down. The switches are spring loaded to neutral position. An aural wholer is generated by the CCAS if trim is used for more than 1 second. Action on this switch will disengage the autopilot.

# 10. Flaps schematic

ATA 27



# 11. Flaps position indicator



ATA 27



ATR 72 PEC



ATR 42 PEC


**EXT flag**

appears to indicate that the flaps valve is hydraulically commanding flap extension. If EXT flag appears when flaps are extended, it means that there is a leak in the flaps hydraulic circuit


**FLAPS position indicator**

shows the flaps position


# 12. Flaps control lever



ATA 27



ATR 72 PEC



ATR 42 PEC

**FLAPS control lever**

controls the flaps operation. Distinct positions correspond to flaps 0°, 15°, 30° (72PEC) or 25°, 35° (42PEC)

# K. Flight instruments

FCOM 1.10





# K. Flight instruments

## 2. EADI



ATA 34

Lateral **ARM** and **CAPTURE** mode

**ROLL ATTITUDE**  
scale 0, 10, 20, 30, 45 and 60°

Vertical **ARM** and **CAPTURE** mode

**Horizon and pitch scale**  
is white and has reference marks at 5, 10, 15, 20, 30, 40 and 60° nose up and 5, 10, 15, 20, 30, 45 and 60° nose down. Above 40° nose up and below 30° nose down, red arrows come into view

**FLIGHT DIRECTOR**  
command bars (magenta)

**FAST/SLOW** indicator  
shows the difference between speed bug and actual speed (±10 Kts)

**GLIDESLOPE** indication

**DH** indication

**LOCALIZER** indication

**Runway symbol**  
appears lower than 200 ft

**RADIO ALTITUDE** indication

**SLIP** indicator



## 3. EHSI



ATA 34

**HDG BUG**  
selected by the remote HDG knob

**NAV SOURCE** annunciator

**POINTER (O)**  
indicates the bearing to a station by N°1 system (VOR 1 or ADF 1).

**DISTANCE display**  
to the selected VOR/DME or ILS/DME station

**POINTER (◇)**  
indicates the bearing to a station by N°2 system (VOR 2 or ADF 2)


**CRS** pointer and deviation

**GROUND SPEED/TIME TO GO**  
annunciator



## 4. EHSI with composite mode

ATA 34




## 5. EHSI - ARC MODE with terrain or weather radar information

ATA 34



## 6. Source failure alert

ATA 34




## 7. Sources switching panel



ATA 34

### ATT/HDG pb

enables to use AHRS 2 information. When captain pb is depressed SYS 2 illuminates white on CAPT pb, CAPT 2 illuminates green on F/O pb



### EFIS SG

enables to use SGU 2 information. When captain pb is depressed SYS 2 illuminates white on CAPT pb, CAPT 2 illuminates green on F/O pb

### VOR/ILS pb

enables to use VOR/ILS 2 information. When captain pb is depressed SYS 2 illuminates white on CAPT pb, CAPT 2 illuminates green on F/O pb

## 8. EFIS control panel



ATA 34

### MAP pb

permits to select MAP selection with waypoints of the flight plan

### GSPD/TTG pb


permits to select ground speed or time to go

### V/L pb

to select the VOR/LOC mode

### FULL/ARC pb

permits to select FULL or ARC mode on EHSI



### RNV pb

to select the GPS mode

### N°1 BRG (○)

selector to select blue bearing pointer to VOR 1 or to ADF 1 or to GPS active waypoints (RB NAV 1)

### N°2 BRG (◇)

selector to select green bearing pointer to VOR 2 or to ADF 2 or to GPS active waypoints (RB NAV 2)

### ADI knob

- outer knob (ADI DIM) to select ON/OFF and to set brightness
- Inner knob (DH TST) to set decision height from -10 to 990 ft + test if you push it
- TEST: to test EFIS System and the radioaltimeter (RA)

### HSI knob

- outer knob (HSI DIM) to select ON/OFF and to set brightness
- inner knob (WX DIM) to set ON/OFF weather radar traces

# 9. Weather radar control



ATA 34

## 9.1. Primus 800

**GAIN**  
setting to set receiving amplification

**TGT pb**  
activates target alert

**GCR pb**  
activates ground clutter reduction function to discriminate echoes usually coming from the ground

**MODE selector**  
**OFF** radar is off  
**STBY** radar is ON but no pulse is sent by antenna  
**TEST** range at 100 NM, 3 arcs green, yellow and red  
**WX** normal operating position, intensity of weather obstacles is displayed by different colors (black: no cloud; green: normal cloud; yellow: dense; red: severe storm)  
**G MAP** enables to display ground obstacles (black, pale blue, yellow, magenta)

**RANGE selector**  
to select the distance scale. 2 concentric arcs of circle are displayed

**RCT pb**  
activates Rain Echo Attenuation Compensation technique function and permits display with more accuracy the weather situation behind storms

**TILT control**  
to adjust radar antenna in pitch axis from 15° down to 15° up

## 9.2. Primus 660

The range pushbutton are used to select the operating range of the radar

**RCT pb**  
activates Rain Echo Attenuation Compensation technique function and permits display with more accuracy the weather situation behind storms

**TGT pb**  
activates target alert

**GAIN**  
setting to set receiving amplification

**MODE selector**  
**OFF** radar is off  
**STBY** radar ins on but no pulse is sent by antenna  
**TEST** range at 100 NM, 3 arcs green, yellow and red  
**WX** normal operating position, intensity of weather obstacles is displayed by different colors (black: no cloud; green: normal cloud; yellow: dense; red: severe storm)  
**G MAP** enables to display ground obstacles (black, pale blue, yellow, magenta)

Turns the pitch and roll stability on and off. When selected off, an amber legend illuminates above the pushbutton

**TILT control**  
to adjust radar antenna in pitch axis from 15° down to 15° up

# 10. AHRS erect PB




ATA 34



**AHRS erect pb**  
illuminates amber when the associated AHRS loses the TAS signal from the ADC.  
If the aircraft is stabilized (unaccelerated level flight) a gyro fast erection may be performed by depressing the associated pb for 15 s.

## 11. TAT / SAT indicator




ATA 34

### TAT indicator

indicates total air temperature

### SAT indicator push button

indicates static air temperature, when pushed



### TAS indicator

indicates true air speed

## 12. CLOCK



ATA 34

### CHRONO

depress once to start, once to stop, once to reset

### TIME KNOB

Pull then rotate knob to set time



### CLOCK

Hours and minutes pointer

### REVOLVING BEZEL

Indicates elapsed time from start mark


## 13. RCDR panel



ATA 34

### RCDR pb

when depressed, both cockpit voice recorder and digital flight data recorder are energized (manual mode). ON It illuminates blue



### RESET pb

when depressed, inhibits recording in the manual mode

## 14. STBY instruments

ATA 34

### STANDBY COMPASS

Hidden in up position. Compass control should be place on DN for use. The compass rose is graduated in 10 degrees increments



### STANDBY AIRSPEED INDICATOR

displays the airspeed as calculated from standby static and standby pitot pressures. Scale from 40 Kt to 320 Kt



### STANDBY HORIZON

Attitude sphere marked every 5 degrees of pitch axis, to  $\pm 80$  degrees. Roll angle is given by a scale marked at 10, 20, 30, 60, and 90 degrees  
Setting knob when pulled, causes a rapid erection if the instrument is powered




### STANDBY ALTIMETER

With baro set knob, altitude pointer and Hpa counter



# 15. Airspeed indicator



ATA 34

**AIRSPPEED INDICATOR**  
displays the airspeed. Scale from 60 Kt to 400 Kt.

**VMO POINTER**  
in red and white strips indicates the max airspeed computed by the associated ADC which represents VMO/MMO. An aural warning (clacker) will be generated by the CCAS if overshoot



**MOVABLE INDICES**  
(bugs) in four colors

**OFF/RED FLAG**  
indicates a failure affecting the VMO channel or the airspeed indicator

**SPEED SELECTOR**  
to set a desired speed during a given phase of flight and controls the reference on the EADI FAST/SLOW scale.

# 16. Altimeter



ATA 34

**ALTIMETER**  
With baro set knob in Hpa and IN HG



**ALTITUDE ALERT**  
It illuminates amber when altitude alert is triggered (-+ 1000 ft or +- 250 ft)

**ALTIMETER**  
With baro set knob in MB and IN HG

# 17. RMI



ATA 34

**Selector switch**  
permit to switch VOR 1 or ADF 1 information which is represented on simple yellow needle.



**RADIO MAGNETIC INDICATOR (RMI)**  
is coupled to the opposite AHRS with a compass rose, showing magnetic heading, two pointers.

**Selector switch**  
permit to switch VOR 2 or ADF 2 information which is represented on double green needle.

## 18. Flight data entry panel



ATA 34

### FLIGHT NUMBER AND DATA ENTRY PANEL

panel enables through 4 thumbwheels to insert different data: hour, minutes, month, day, year.

### EVENTS pb


When momentarily depressed, the tape records are marked to identify a special event

### STATUS SYST Lt

illuminates amber when  
 - the DRDR is failed  
 or - the DFDR or QAR (if installed) (quick access recorder) electrical power is lost  
 or - QAR (if installed) 80 % full

### STATUS FDAU Lt

illuminates amber when the FDAU is failed




### DATA DISPLAY

Date and time may be displayed and selected through the UPDATE pb and the data entry panel

### UPDATE pb

first left thumbwheel of data entry panel must be on 9 position  
 - first sequence: hours and minutes  
 UPDATE pb depressed, the display flashes,  
 insert hour and minutes,  
 UPDATE pb depressed, correction is taken into account and is displayed for 5 seconds  
 - second sequence: month and day  
 - third sequence: year

## 19. TCAS VERTICAL speed indicator



ATA 34

### TEST switch

activates indicator self-test when depressed, indicator will display a test pattern

### OPEN DIAMOND

shows other traffic. Range and bearing of other aircraft within surveillance range and selected range and altitude for display

### GREEN ARC

recommandes vertical speed to resolve corrective resolution advisory

### POINTER

(white) indicates present vertical speed. Pointer displayed when vertical speed is valid

### SOLID CIRCLE

intruder. TA generated. Range and bearing relative to own aircraft

### A/B Mode button

select display of traffic (relative to own aircraft altitude)  
 ABOVE: +9900 ft to -2700 ft  
 BELOW: +2700 ft to -9900 ft  
 In normal position, viewing of traffic from 2700 ft below to 2700 ft above

### TRAFFIC DATA

(same color as associated traffic symbol): relative altitude of intruder aircraft. If altitude is not available, traffic data is not displayed

### RANGE (6 NM or 12NM)

selected forward range of traffic display

### SOLID DIAMOND

traffic within  $\pm 1200$  ft and 6 NM of own aircraft

### TRAFFIC ARROW

(same color as associated traffic symbol): climb or descent rate (>500 ft/min) of intruder aircraft

### TRAFFIC DATA

Relative altitude of intruder aircraft

### SOLID CUBE

traffic generates conflict. RA generated range and bearing relative to own aircraft

### AIRCRAFT

own aircraft symbol

### RNG

Range push button selects range of display. (6NM or 12NM)

### RED ARC

do not enter range if vertical speed is outside of arc (preventive); Exit range if vertical speed is within arc (corrective resolution)

### RANGE RING

(white) 2 miles radius range about own aircraft



# L. Fuel system

FCOM 1.11



## 1. Schematic


ATA 28

The fuel is stored in two tanks, one in each wing. Each tank is fitted with:

- a vent surge tank to ensure positive pressure and allows a thermal expansion without spillage
- a main wing tank
- a feeder tank, always full to protect the engine feed system against negative or lateral load factors


ATR 42

Total quantity 4500 kg




ATR 72

Total quantity 5000 kg



## 2. Starting procedure

ATA 28



### ENGINE SHUT DOWN WITH ELECTRICAL PUMP RUNNING

Both fuel engine electrical pumps push buttons are pressed IN and green RUN lights illuminate.

The electrical pumps are energized and begin to supply fuel to engines.


The FEED LO PR amber light extinguishes when the pressure is > 4 psi on the line.

At the same time, the feeder jet pump is activated by the electrical pump output pressure, to supply and maintain the feeder tank full.




# 4. Cross feed procedure

ATA 28




Cross feed valve could be used to supply an engine from the opposite tank. The cross feed is not used to transfer fuel from one tank to the other tank. With the Xfeed valve push button pressed IN, the valve opens, green flow bar is horizontal. Both electrical pump are energized.



By selecting OFF the corresponding PUMP push button, the electrical pump is de-energized and the motive flow valve is supplied to close. The engine is fed through the opposite tank.

## 5. Engine feed jet pump low pressure ATA 28




In the event of engine feed jet pump failure, the pressure switch (< 5 psi) provides electrical pump running control which ensures fuel supply to the engine.

The electrical pump delivers the necessary flow rate for engine consumption.

## 6. Low level

ATA 28




When the low level is triggered on one tank, its electrical pump is automatically activated.

Two cases of low level:

- LO LVL with fuel quantity indicator < 160 kg → Low level of the remaining fuel in the tank.
- LO LVL with fuel quantity indicator > 160 kg → Feeder tank not full due to a failure of the feeder jet pump. In this condition, the fuel is transferred from the main tank to the feeder tank through the flappers.


7. Engine fire procedure

ATA 28



In case of engine fire, when corresponding engine fire handle is pulled, it closes associated LP shut off valve.

## 8. Fuel panel



ATA 28

### FEED LO PR


Delivery pressure < 4 PSI.  
Pump failure or fuel starvation.  
CAP.

### FLOW BAR

Shows position of valve. No bar: valve fault or moving.

### RUN

illuminates green when elec fuel pump is running.



### XFEED valve

Activates both elect fuel pumps.

### PUMP

Control electrical pump power and jet pump motive flow valve.

Runs automatically if:

- jet pump press < 5 PSI or till reaching 8.5 PSI during engine start.
- XFEED in line
- fuel LO LVL
  - \* When the quantity is < 160 kg
  - or \* When the quantity is > 160 kg, but the feeder tank is not full (Feeder jet pump failure)
- during fuel quantity test

FUEL TEMPERATURE in °C


## 9. Fuel QTY panel



ATA 28

### LO LVL Lt

- When the quantity is < 160 kg or
- When the quantity is > 160 kg, but the feeder tank is not full (Feeder jet pump failure)



### TEST pb

When pushed in, displays all 8'S + LO LVL LTS + CAP + elect pumps energized. Refuel valves auto close.

## 10. XFEED advisory light



ATA 28



### FUEL X FEED

Illuminates as soon as the fuel crossfeed is selected on.

# M. Hydraulic system

FCOM 1.12




# 1. Schematic

# ATA 29

The aircraft has two hydraulic systems, designated blue and green. Each system is pressurized by an electric pump, supplied by ACW power. The blue system is also provided with an auxiliary pump, supplied by DC power (automatic or manual mode).


Total fluid volume:	9.6 l
normal filling:	9.35 l
minimum filling:	8.5 l
alert level:	2.5 l




## 2. HYD PWR panel




ATA 29



## 3. Pressure indicator




ATA 29



## 4. AUX pump pedestal switch



ATA 29



**AUX PUMP pedestal switch**  
 - energizes for 30", the auxiliary DC hydraulic pump with the HOT MAIN BAT BUS  
 - supplies power to the pressure indicators  
**NOTE:** intensive use could discharge the main battery.

# N. Ice and rain protection

FCOM 1.13



Aircraft ice protection is provided by a pneumatic and an electrical system adapted for the critical areas. Ice detector monitors ice accretion. It is connected to the CCAS.

## 1. Schematic

## ATA 30

AILERON HORNS  
(ELECTRICAL)



WINGS BOOTS  
(PNEUMATIC)



ENGINE AIR  
INTAKE BOOTS  
(PNEUMATIC)



HORIZONTAL TAILPLANE BOOTS  
(PNEUMATIC) / RUDDER  
AND ELEVATOR HORNS  
(ELECTRICAL)



WINSHIELD  
(ELECTRICAL)



PROPELLER  
(ELECTRICAL)



SIDE WINDOWS  
(ELECTRICAL)



ICING EVIDENCE  
PROBE



PROBES  
(ELECTRICAL)




ICE DETECTOR




## 2. Probes and windshield HTG




ATA 30




## 3. Rain protection




ATA 30



## 4. Ice detector panel and icing AOA




ATA 30




## 5. De-icing schematic

ATA 30

ATR 42




ATR 72



## 6. Anti-icing & de-icing panel

ATA 30



## 7. De icing indicator (memo panel)



ATA 30

**DE ICING LIGHT**  
– Illuminates when airframe deicing syst is ON  
– Flashes when airframe deicing syst still selected ON 5 min after last ice accretion detection



# 0. Landing gear

FCOM 1.14




# 0. Landing gear

## 1. Landing gear description


ATA 32

The landing gear is hydraulically operated. In case of hydraulic failure, it may be extended by gravity.



## 2. Brakes schematic

ATA 32



### 3. LDG GEAR position indicators

ATA 32


**System 2**

**UNLK** gear not locked in selected position or (on GND) uplock box not opened.  
**Green** Lt down lock engaged



**System 1**

**UNLK** gear not locked in selected position or (on GND) uplock box not opened.  
**Green** Lt down lock engaged.



### 4. Landing gear handles

ATA 32

**LDG GEAR EMERGENCY EXTENSION HANDLE**

permits to unlock the landing gear




**GEAR HANDLE RED LIGHT**  
 any gear not sensed down and locked with some conditions. CAP.

### 5. Brakes temperature and antiskid

ATA 32

**BRK TEMP**

**HOT** Any brake T° > 160°C



**F (FAULT)**

wheel channel failure. CAP



**OFF**

Pb released, system deactivated

**ANTISKID**

Operative if speed > 10 kts.  
 Activates when speed > 23 kts + 50% diff between wheels (locked wheel protection).  
 Braking action inhibited at touchdown as long as wheel spin up speed < 35 kts or 5 sec. (touchdown protection).  
 CAUTION: THE TEST INHIBITS BRAKES


TEST pb  
 (inhibited if speed > 17 kts)  
 = MC + SC CAP 4F amber lt.  
 Test duration: 3 sec. in flight and 6 sec. on ground

### 6. Emergency parking brake handle

ATA 32

**EMERGENCY BRAKE HANDLE**

permits to apply a metered pressure. The brake accumulator allows at least six braking applications without any antiskid operation if the blue hydraulic system is not available)



**PARKING BRAKE**


permits a full pressure on the brakes. When brake handle is not in the fully released position, amber PRKG BRK caution light illuminates on CAP and is taken into account by the T/O CONFIG. (Springloaded to the off position)

### 7. Steering handwheel

ATA 32

**N/W STEERING SW**

activates or deactivates the nose wheel steering system (guarded type in the ON position)  
 OFF: unpressurizes the steering system (91° of deflection)



**THE STEERING HAND WHEEL**

controls the nose wheel angle up to 60° in either direction:  
 - clockwise: steering to the right  
 - counter clockwise: steering to the left

# P. Navigation system

FCOM 1.15



## 1. Nav control box



ATA 34

### NAV

**POWER SELECTOR** to energize the control box and associated VOR/ILS/DME receivers.

**HLD**: holding the DME on the current active frequency



### XFR/MEM switch

XFR exchanges active and preset frequency  
MEM to activate frequencies stored in the memory

### ACT

Direct active tuning mode. to change directly the active frequency

## 2. Marker switch




ATA 34



### MKR SW

is used to set marker sensibility

## 3. ADF control box



ATA 34

### ADF

**OFF**: ADF deenergized

**ANT**: The antenna loop is disabled and the receiver is used as a conventional receiver the RMI pointer will park horizontally

**ADF**: The system operates in ADF mode and provides the bearing

**TONE**: A 1000 Hz sound indicates that ADF is correctly tune to the station



### XFR/MEM switch

XFR exchanges active and preset frequency  
MEM to activate frequencies stored in the memory

### ACT

Direct active tuning mode. to change directly the active frequency

## 4. EGPWS alert modes

ATA 34

The Enhanced Ground Proximity Warning System provides visual and aural alerts in case of dangerous flight path conditions which would result inadvertent ground contact if maintained.

The EGPWS performs the following alert modes:


– Basic GPWS modes

- \* Mode 1: excessive descent rate
- \* Mode 2: excessive terrain closure rate
- \* Mode 3: altitude loss after take-off
- \* Mode 4: unsafe terrain clearance
- \* Mode 5: below glideslope
- \* Mode 6: altitude callouts



– Enhanced modes:

- \* Terrain Clearance Floor (TCF)
- \* Terrain Awareness & Display (TAD)


**MODE 1**  
excessive descent rate





**MODE 2**  
excessive terrain closure rate




**MODE 3**  
altitude loss after take-off




**MODE 4**  
unsafe terrain clearance



**MODE 5**  
below glideslope






**MODE 6**  
altitude callouts






**TERRAIN CLEARANCE FLOOR**

The Terrain Clearance Floor (TCF) mode creates an increasing terrain clearance envelope around the airport runway directly related to the distance from the runway.



**TERRAIN AWARENESS & DISPLAY**

This function use the aircraft geographic position from the GPS, aircraft altitude and a worldwide terrain database to predict potential conflict between the aircraft flight path and the terrain, and to provide aural alert and graphic displays of the conflicting terrain.



**5. EGPWS pb**



**ATA 34**




**GPWS** illuminates red as long as any mode 1-2-3-4 alert is activated, accompanied by the voice alert for the particular mode

**6. EGPWS selector**




**ATA 34**




**EGPWS selector** is guarded in the norm position. **FLAP OVRD** mode 4 alert caused by flap extension is inhibited to avoid nuisance in case of flapless landing

## 7. Global navigation satellite system (GNSS)



ATA 34



The Global Navigation Management System (GNSS) receives and processes Global Positioning System (GPS) signals. The GNSS provides en route and terminal area guidance, autopilot coupling, roll steering and vertical deviation (non-coupled), along defined flight plan, selected on the MCDU

Composite image showing navigation displays and control panels with callouts 1, 2, and 3. Callout 1 points to the MCDU display showing flight plan waypoints. Callout 2 points to the MAP and RNV P/B on the EFIS control panel. Callout 3 points to the NAV mode on the autopilot control panel.

Lateral navigation tracking

Vertical deviation scale

Flight plan waypoints  
Next waypoint (magenta)  
Other waypoint (white)

- 1 Selection of a flight plan and vertical navigation profile
- 2 Selection on MAP and RNV P/B on the EFIS control panel
- 3 Selection of the NAV mode on autopilot control panel

# Q. Power plant

FCOM 1.16



## 1. Engine schematic


ATA 61/72

Aircraft fitted with

- two Pratt &Whitney, PW 127 F (72-212A), E (42-500) or M (42-500/72-212A)
- two, six blades propellers (Hamilton)

It is a free turbines engine, composed of 3 concentric shafts of spools:

- The shaft of the HP spool composed of the HP turbine and the HP compressor (rotation speed of the HP spool: NH). The HP spool drives the accessory gear box (AGB)
- The shaft of the LP spool composed of the LP turbine and the LP compressor
- The Power shaft composed of 2 power turbines (Free turbines). This 2 power turbines drive the propeller through the reduction gear box (RGB) (rotation speed of the propeller NP)



6 blades propeller

## 2. Power and propeller controls

ATA 61/72

The different powers of the engine are: (SHP: Shaft Horse Power)



	72-212A	42-500
- RTO (Reserve Take Off) (maximum power) Used in case of an engine flame out during take off (up trim) or in case of go around (ramp)	2750 SHP	2400 SHP
- MCT (Maximum continuous)	2500 SHP	2400 SHP
- TO (Take Off 0,9 RTO)	2475 SHP	2160 SHP
- Climb	2192 SHP	2160 SHP
- Cruise	2132 SHP	2132 SHP

Power (PWR) = Torque (TQ) x NP

For the same power: If TQ increases, NP decreases  
If TQ decreases, NP increases

Power setting is characterized by constant power lever (PL) and condition lever (CL) positions. The power adapted to the flight phase is selected by the pilot through a power management selector (PWR MGT).



- With input coming from the PWR MGT and the position of the PL, the EEC (Engine Electronic Control) control the fuel flow to the engine.



- MAX PWR (Full stop): Maximum Power → TQ up to 115% (On emergency only)
- GO around position (Beginning of the ramp): RTO → TQ up to 100%
- NOTCH position:
  - PWR MGT in - TO: → NP 100% and 0,9 RTO → TQ up to 90%
  - MCT → NP 100% and TQ up to 90,9% (72-212A)  
→ NP 100% and TQ up to 100% (42-500)
  - CLB → NP 82% and TQ up to 97% (72-212A)  
→ NP 82% and TQ up to 109,7% (42-500)
  - CRZ → NP 82% and TQ up to 94,5% (72-212A)  
→ NP 82% and TQ up to 108,3% (42-500)
- Reversion in manual mode when EEC FAULT (green band <52°)
- Flight Idle position
- Ground Idle position
- Reverse position

## Q. Power plant

– With the input coming from the PWR MGT and the position of the CL, the PEC (Propeller Engine Control) control the NP (propeller speed) by changing the blades angle.



Regardless of the PWR MGT position, NP is at 100%

AUTO position:

→ Blade angle governing mode. The NP is regulated by the PEC (Blade angle change). PWR MGT in:

- TO → NP = 100%
- MCT → NP = 100%
- CLB → NP = 82%
- CRZ → NP = 82%

→ Fuel governing mode. The NP is regulated by the EEC (Fuel Flow change) ground operation in low power. The NP is maintained at 70.8% to have the ACW available. (The ACW generator is on line when NP > 66%)


FTR (Feather position). The fuel governing mode is cancelled (No ACW generator)

Fuel Shut Off position: Close the shut off valve on the HMU



- The PWR MGT has four positions: TO, MCT, CLB, CRZ  
 - Considering that CLs are in AUTO and the PLs are at this position marked by the notch, the control system delivers max rated power corresponding to the mode selected (the max rated power is delivered only when the engine is not thermodynamically limited)

## ATR 72-212A




- TO	PWR = 2475 SHP	NP=100%	TQ = 90%
- MCT	PWR = 2500 SHP	NP=100%	TQ = 90,9%
- CLB	PWR = 2192 SHP	NP=82%	TO = 97%
- CRZ	PWR = 2132 SHP	NP=82%	TO = 94,5%

The RTO (Reserve Take-Off) is obtained in case of up trim (one engine out during take off) or with the PL to the ramp

- RTO	PWR = 2750 SHP	NP=100%	TQ = 100%
-------	----------------	---------	-----------

## ATR 42-500




- TO	PWR = 2160 SHP	NP=100%	TQ = 90%
- MCT	PWR = 2400 SHP	NP=100%	TQ = 100%
- CLB	PWR = 2160 SHP	NP=82%	TO = 109,7%
- CRZ	PWR = 2132 SHP	NP=82%	TO = 108,3%

The RTO (Reserve Take-Off) is obtained in case of up trim (one engine out during take off) or with the PL to the ramp

- RTO	PWR = 2400 SHP	NP=100%	TQ = 100%
-------	----------------	---------	-----------

## 3. Engine indicators



ATA 61/72

### INTERNAL BUG

computed by FDAU; shows RTO MGT on T/O, otherwise max TQ depending on PWR MGT selection

### TORQUE ind. (DC EMER)

2 probes located on the reduction gear box shafts sends signal to the AFU (Auto Feathering Unit) and to the EEC (Engine Electronic Control) which supply the torque indicator. The AFU controls the pointer and the EEC controls the digital display

### NP ind.

DC ESS from 0 to 120%

### ITT ind.

(DC ESS) from 0 to 1200°C  
Red point: 20" max  
Red point + S: 5" max on start  
H: limite for hotel mode operation

### TEST

115 % (blue dot)

### OIL PRESS ind.

(Main DC BUS) from 0 to 90 PSI

### OIL LOW PRESS Lt

<40 PSI. A separate press sw activates CCAS below 40 PSI

### OIL TEMP

(Main DC BUS) from 0 to 130°C

### FUEL USED readout

(Main DC BUS)

### TORQUE ind.

white TQ bug manually selected

### TEST

115 % (blue dot)

### KNOB

to set white TQ bug

### NP ind.

NP actual display

### TEST

115 % (blue dot).

### ITT ind.

ITT actual display

### ALERT

When ITT > 800°C or 715°C in hotel mode Lt CAP

### TEST

1150°C (blue dot)

### NH /NL ind


(DC ESS) NH actual display from 0 to 120%

### FUEL FLOW Ind.

(Main DC BUS)

### FU reset knob


FU reset to 0 when pulled




# 4. ENG START panel




ATA 61/72




# 5. ENG control panel



ATA 61/72



## 6. PWR MGT panel




ATA 61/72

### PWR MGT

2 co-axial sw. (LH: bottom / RH: TOP) providing FDAU, PEC and EEC with basic power requirements

### OFF

PEC is deactivated and NP is limited at 102,5% if power is sufficient



### SGL CH


illuminates when one channel is lost (2" for self test when advancing CL from FTR to AUTO)

### FAULT


illuminates when both PEC channels are lost. CAP

42/72 PEC

## 7. ATPCS test panel



ATA 61/72



### ATPCS

selector allows to check the correct functioning of the ATPCS. This rotary selector is spring loaded to neutral position


## 8. Idle gate



ATA 61/72

### IDLE GATE FAIL

light illuminates amber and the CCAS is activated when the gate does not engage automatically in flight or does not retract at landing



### IDLE GATE LEVER

enables manual override in case of failure of the automatic logic or no DC power. In flight: push. On ground: pull. A red band appears

# Annexes



## Annex 1. Cockpit panels

### SQUIB TEST

Elect test of squibs.

### FAULT

resistance/capacitance. Inhibits fire signals until turned off.

LOOP in CAP (DC EMER)

### SQUIB

armed when T handle pulled. Discharges bottle.

(DC EMER / HOT MAIN BAT).

### DISCH

bottle depressurized. Opposite agent DISCH Lt will also illuminate on other fire panel.

### TLU FAULT

system disagree / two ADC failures / ADC datas incoherence / TLU position synchro failure. T/O or T/O Config Test and TLU not LO SPD

### TLU manual operation

Above 195 kts (42) / 185 kts (72): HI SPD  
Below 190 kts (42) / 180 kts (72): LOW SPD

### SPLR

activates when >2.5° aileron travel. Lt ON=spoiler not fully retracted (BLUE HYD PWR).

### Light on when SW TEST

depressed and all door micros are opened. (Passengers and service doors opened)

At least 1 microsw is opened. (DC BUS 2)

Tests continuity of microsw. System (on ground, doors opened).

Fuel delivery pressure below 4 PSI. Pump failure or fuel starvation. CAP.

Shows position of valve. No bar = valve fault or moving.

### RUN

Illuminates green when elec fuel pump is running.

### OFF

disconnect the elec pump and force to close the motive flow valve

Feeder Tk Fuel Temp Ind LH only (DC BUS 1) (Range -60°C/0°C)

Both domes (DC BUS 1) F/O only in basic mode (DC EMER).

Use in basic mode to limit Lts in cabin. Light on the RH side only.

Two fluorescent lights under glareshield.

### ENGINE FIRE HANDLE

Pulled: on the respective engine  
Prop Feather  
Fuel LP valve closed  
Air Bleed valve closed  
Deice Deice & shutoff valve closed  
Elect DC & ACW gen. disconnected  
Squibs Armed (Lts illuminated)  
Hydraulic Hyd prop brake (eng 2 only)

### Fire test

MW+CR+ ENG 1 FIRE on CAP  
+Fire handle illuminated  
+FUEL S/O Lt on CL (if out of Fuel S/O position)

### Fault test

MC+SC+ loop on CAP  
FAULT Lts on A/B Loop pb.

### OFF

Takes respective loop out of parallel circuit. Allows other loop to activate fire signal.

The opening of the cargo door control panel cover. Self Test of MFC 1A/2A.

### FAULT

Malfunction or electrical supply fault: AUTO disengagement – CAP  
Most amber LTS / some red LTS are lost on CAP if dual fault of 1B & 2B.

Gear position secondary system as sensed by MFC 2.

### UNLK

gear not in selected position or uplock not opened (on Gnd)

### Green Lt

down lock engaged

Controls XFEED valve. Activates both elect fuel pumps.

Controls elect pump power supply and jet pump motive flow valve.

Runs automatically if:  
Jet pump press <5 PSI  
or Xfeed in line  
or Fuel LO LVL  
- <160 kg  
- >160 kg (with feeder tank not full)  
or During Fuel Quantity test


To call cabin from cockpit (SC)

To be called by cabin attendant: blue Lt and door bell.  
Cancelled when pressing RESET pb.

To call mechanic= HORN is activated.

To be called by mechanic: Blue Lt and Door Bell.  
Cancelled when depressing RESET Pb

Do not use above 160 kts. ESS BUS.



**UNDV**  
DC STBY <19.5V. No CAP.

**OVRD**  
Transfert of STBY buses from HOT MAIN to HOT EMER BAT BUS.

**INV FAULT**  
Inv failure or supply loss  
Auto-Xfer of all AC buses to remaining inverter. CAP.  
Emergency supply indicators (Amber arrows) (Respective battery discharging).

**ON**  
Pb pressed IN (ON illuminated WHITE). TRU is connected to ACW BUS 2 – ARROW illuminates amber when supply of DC EMER BUS, DC STBY BUS, INV 1 (AC STBY BUS) and DC ESS BUSS from TRU is effective.

**FAULT**  
Battery charger failure detected by MFC. CAP.  
Contactor Auto opens (MFC) if: thermal runaway/Bus voltage <25V / start sequence/Bat sw on OVRD.  
Respective bus not supplied. CAP.

**SHED**  
One of the DC SVCE / UTLY 1 and 2 busses is shed (BPCU). CAP.  
OFF: all the DC SVCE BUS/ UTLY 1 and 2 busses are shed  
Opposite generator has not come on line to assist start at 10% NH (on ground only).  
Generator FAULT LT  
Extinguishes above 61.5% NH if GEN is operating normally.

**ON**  
started engaged. At 45% NH, light out, starter disengages automatically.

**CRANK**  
dry monitoring (no ignition).

**START**  
selects a start sequence. In flight regardless of start selection (A, B, A+B) both exciters are energized.

Prop Brake not fully locked or not fully released. After 15 sec = **CAP.**

Supplied by ACW.



On external power, pedestal PB must be on to power CVR test

Associated bus deenergized. **CAP.**

**OVRD**  
insures basic mode operation by overriding all other protections.

**ON**  
**Basic mode:** STBY Busses supplied by HOT MAIN BAT BUS.  
**EXT or GEN power:** DC STBY BUS transferred to HOT EMER BAT BUS; AC STBY BUS to DC BUS 1.

**OFF**  
ESS BUS, DC STBY BUS + INV 1 are isolated from HOT MAIN BAT BUS.  
DC EMER BUS is isolated from HOT EMER BAT BUS.  
Allows BPCU to control BTC operation (Bus Tie Contactor). Ext power, Hotel mode or single gen operation. BTC is closed (green flow bar).

**ISOL**  
BTC opened (released out).  
BTR (Bus Tie Relay) locked open (Tie between AC Busses)

**AVAIL**  
GPU has been checked by BPCU for over/under voltage, over current and polarity.

**AVAIL+ON**  
The GPU supplies the electrical system. GPU has priority on both generators.

**FAULT**  
Protection triggered by GCU. Auto reset if underspeed: in other cases manual reset. BTC auto closes.

**FAULT**  
illuminates when:  
starter remains ON with NH>45%  
or GCU failure during start or starter failure  
or ENG2 only PROP BRK ON+Gust lock not engaged (Starting not inhibited).

**ON**  
Continuous ignition (both A & B). Memo panel light.

**READY**  
engagement or disengagement cond. Are met:  
– A/C on ground  
– gust lock engaged  
– CL on FTH of FUEL S/O  
– blue hyd press > 2100 PSI  
– fire handle not pulled

**PROP BRK**  
Prop brake fully locked. Memo panel light.

Supplied by DC SVCE BUS (Back up DC BUS 1).  
Supplied by DC BUS 2.

## Main BLUE PUMP

Supplied by ACW, controlled by DC EMER BUS.

## AUX PUMP

Running conditions:

- AUX PUMP pb depressed
  - at least one engine running
  - blue system press < 1500psi
  - prop brake off
  - gear lever down
- (supply: DC BUS 2 or HOT MAIN BAT BUS)

## OVHT

Temp >121°C (250°F). **CAP** (no auto off)

Associated bus not supplied

## AVAIL

GPU has been checked by BPCU

## AVAIL + ON

GPU supplied ACW system. GPU has always the priority on both GEN

AUTO reset in case of under/over speed: manual reset otherwise. ACW SVCE BUS auto shed if one GEN is out.

## ALPHA

ACW supply  
Amber LT illuminates in case of Failure or Pwr loss. **CAP**.

## TAT

no heated. **CAP** (ACW supply). Heating inhibited on ground.

## PITOT

tube not heated. **CAP** (ACW BUS for CPT & F/O).

## PITOT STBY

not heated (CAP).  
ACW bus 1 or 115 AC STBY BUS as back up.

## ON

ACW supply (inhibited when NP <63%).

## FAULT

power loss on at least 1 Blade. **CAP**.

## NORM

10 sec on per 3 blades; then 10 sec off between cycles.

## ON

## HIGH POWER

20 sec on per 3 blades. No pause between cycles (ON LT illuminates BLUE).

## MODE SEL AUTO

Automatic selection of cycle depending on ADC1/2 input to MFC1B/2B.

## FAULT

when ADC or MFC fail  
Fast mode is automatically selected for ENG and AIRFRAME DEICING and High Power for Prop Anti-ice.

## MAN

mode enables manual selection of cycles depending on SAT (MAN illuminated WHITE).

DEICE air is always available regardless of bleed pb.


FAST: 60 sec / cycle  
SLOW: 240 sec / cycle (SLOW illuminates BLUE)

## FAULT

distribution valve opened but no air press.  
OR valve closed and press. Detected  
OR air temp upstream of the deice valve >230°C for more than 6 sec.

## ON

deice valve opened even if AFR AIRBLEED off.



## Main GREEN PUMP

Supplied by ACW, controlled by DC ESS BUS.

## XFEED

PB released. Xfeed closed  
PB pressed: ON LT illuminated WHITE, Xfeed valve selected OPEN. (Except in case of LO LVL where the Xfeed is locked closed)

## LO PR

pump delivery pressure less than 1500 psi. **CAP**. No auto off.

## LO LEVEL

associated compartment <2,5 ft **CAP**. Xfeed opening inhibited.

## BTC

Allows BPCU to control BTC operation.  
Ext Pwr or simple GEN operation: BTC is closed (Green Flow BAR).  
Auto closure when either ACW GEN drops off line.

## ISOL

BTC opened (Pb released out).  
Min Np for ACW= 66%.

## FAULT

Power loss or failure; **CAP**.

## STAT

Static source not heated or failed. **CAP** on ground only (DC BUS). (no alarm in flight)

## ON

Defog only.

## FAULT

for power loss or failure; **CAP** (DC BUS).

## ON

ACW supplied. Horns heating inhibited on ground; either horn activates AOA LT.

## FAULT

Power loss. **CAP**.

## FAULT

valve opened but no downstream press. OR valve closed and downstream press. Detected. **CAP**.

## ON

signal sent to MFC to start deice cycle on the airframe.

## FAULT

both MFC modules controlling boots have failed resulting in an incorrect inflation sequencing.

## OVRD

no MFC. Boots inflated by a separate standby controller. Fast cycle only (cycle 60°).

## FAULT

Air downstream deice valve <14 psi more than 10 sec. Air upstream deice valve >230°. **CAP**.

## OFF

isol valves closed. Deice valves closed unless ENG 1/2 deice on.

Blue Lts on MEMO panel when ON (DC BUS2).

## ON

emergency exit lights illuminated. Supply: 6V Bat packs.

## ARM

- lights on if DC STBY BUS <18V  
- lights off if DC STBY >20V  
- or in case of dual DC GEN loss

## DISARM

system deactivated

Tests all three smoke detections (elec. fwd. aft smoke Red alarms in CAP).  
Stops extract fan, only on ground (FAULT on EXHAUST MODE).  
To restart extract fan it is necessary to reset EXHAUST MODE Pb

PB in: Crew supply only.  
If below 1400 psi, use table.

**NORM**  
- On ground, ENG 1 off: extract fan on. Ovbd valve full open, U/F valve closed.  
- On ground, ENG 1 on: extract fan on. Ovbd valve closed, U/F valve opened.

**FAULT**  
Fan failure / overheat (fan inhibited for 120s after every eng start. AIR light in CAP).

**OVBD**  
Extract fan off. OVBD valve partially opened (in fight only). U/F valve closed.

Duct temperature limited to 88°C. (191°F) by pneumatic temp limiter.

**NORM:** 22 psi  
**HIGH:** 30 psi regulated by pack valve


Spring loaded closed. Ground only. Auto opens when only 1 Bleed valve is opened.

Controls both Bleed and HP valves. Spring loaded closed. Must have air & elec to open. Auto Bleed valve closes when Ovht, Leak, Overpressure (> 80 psi), Fire T pulled, when UPTRIM is triggered or prop brk on (left one only). Inhibited during eng start.

**FAULT**  
Bleed valve disagreement with selected position (case of Ovht, Overpressure or Leak).  
**CAP.** Associated valves auto closed.

**OVHT**  
either bleed duct temp thermal switch above 274°C.  
**CAP.** Associated valves auto closed.  
May be reset after cooling.

Do not use above 160 knots. DC BUS 2.



**FAULT**  
fan inop. CAP.  
**ALTN**  
activates altn fan.

**LO PR**  
supply below 50 psi.  
**ON**  
25% of Pax are supplied.

**FAULT**  
Ovbd Valve in disagreement with Ovbd Valve SW position.  
AUTO except for emergency. In emergency, the full open position is possible only if the Delta P is < 1 psi

Assists pack air flow.  
**FAULT**  
Fan low speed or motor overheat. **CAP.** No auto deselected.

**OVHT**  
Duct overheat > 92°C. CAP. Pack valve will not auto close.  
**MAN**  
Compt temp knob controls directly temp control valve.  
Selects the zone where T° check is desired.

**PACK VALVE**  
Spring loaded closed. Must have air pressure and select power to open (6 sec delay on RH pack for pax comfort).  
**FAULT**  
pack valve disagreement with PB or Ovht downstream of pack comp (>204°C). CAP. Valve auto closed.

**LEAK**  
activates when temperature detected by bleed loop exceeds 156°C. **CAP.**  
Auto closure after 1 sec of following valves: Bleed, HP, PACK and GND XFeed. DO NOT RESET BLEED.

Tests all lights except LO LVL, ITT and FDEP (DC BUS 2).  
Fuel Qty. TAT/TAS. Ldg Elev indicators show all 8 sec.

**STBY HORIZON (DC EMER)**  
Red and black flag: elec supply loss or gyro speed insufficient.

**STBY IAS and ALT Ind**  
both supplied by Stby pitot and static source: completely independent from CPT / F0 systems.

**PWR MGT**  
2 co-axial sw, (LH: Bottom/ RH: Top) providing FDAU, PEC, PIU and EEC with basic power requirements.

**SGL CH**  
illuminates when one channel is lost (2 sec on, for self test when advancing CL from FTR to AUTO).

**FAULT:** illuminates when both PEC channels are lost **CAP**.  
**OFF:** PEC is deactivated and Np is limited at 102.5% by the overspeed governor if power is sufficient.

**TEST pb**  
when pushed in, displays all 8's + LO LVL LTs, + **CAP** + elect Pumps energized. Refuel panel disabled during test and refuel valves auto close.

**LO LVL Lt**  
– When the quantity is <160kg or  
– When the quantity is >160kg, but the feeder tank is not full (Feeder jet pump failure)  
Elec pump auto runs. **CAP**.

**TAS Ind**  
from selected ADC indicates TAS from 68 to 600 kts; if ADC not valid it displays (---).

**TAT Ind**  
from selected ADC Indicates TAT; If ADC not valid , it displays (---).

**SAT pb**  
shows SAT when depressed and held.

**FAULT**  
detector failure or supply loss (ACW BUS 2). **CAP**. (FAULT LT supplied by DC EMER).

**ICING steady**  
ice accretion is detected and both horns anti icing + airframe deicing are selected ON. MC + SC.

**ICING flashing**  
ice accretion is detected and either horn and/or airframe selected OFF. MC + SC.

**PTT pb**  
press for 3 sec.  
– icing will flash if system works correctly.  
– FAULT LT illuminate steady if ice detector failure is detected.

**ICING AOA Lt**  
illuminates green as soon as 1 horn anti-icing ON. Stall alarm (stick shaker threshold lowered). It can be extinguished manually only by releasing ICING AOA Pb (DC EMER) provided both Horns anti-icing selected OFF.



**Arming conditions:**

PWR MGT sel on TO  
 +ATPCS pb in  
 + both PL >49°  
 + both TQ > 53%(42)  
 both TQ > 46% (72)  
 ARM green LT on.

**UPTRIM**

signal sent to respective eng during ATPCS sequence. Eng power = RTO.

**LO PITCH**

blade angle < 8° (below FI) CAP in flight only.

**TORQUE Ind (DC EMER)**

2 probes sending info:  
 - to pointer (via AFU).  
 - to digital counter (via EEC).

**Internal bug**

computed by FDAU; shows RTO when PWR MGT on TO, otherwise max TQ depending on PWR MGT selection.

**NP Ind**

(DC ESS)

**LIMITS**

From 0 to 120%.

**TEST**

115% (blue dot).

**ITT Ind**

(DC ESS)

From 0 to 1200°C.

Red point: 840° (20 sec max)

Red point+S: 950° (5 sec max on START).

**FUEL CLOG**

Fuel press loss in corresponding HP pump fuel filter (DC BUS 1/2)  
 $\Delta$ PSI >25 PSI: CAP  
 Filter blocked and by-passed when  $\Delta$ PSI >45.

**FUEL TEMP Ind**

sensor before HP pump (DC BUS 1/2).  
 From -54 to +57°C.

**OIL PRESS**

(DC BUS 1/2).  
 From 0 to 90 psi

**OIL LOW PRESS Lt\***

< 40 PSI. A separate press sw activates CCAS below 40 PSI

**ATPCS**

- ARM on ground = uptrim + auto FTR (2.15" delay)  
 - ARM in flight (In case of go around) = auto FTR only.

**ATPCS**

**Trigger**

one TQ <18% (42)  
 one TQ <18% (72).

**Cancel**

PWR MGT out of TO  
 or ATPCS pb OFF  
 or at least one PL retarded <49°  
 or both TQ <53%.

**EEC**

acts on stepper motor, to regulate Fuel Flow.

**FAULT flashing**

EEC Failure. The fuel flow is frozen to maintain the power. (Do not deselect EEC when flashing)

The PL has to be retarded to the green sector before deselection of the EEC

**FAULT steady**

EEC Failure. HMU base law = reversion. Fault become steady when the PL is retarded in the green band.

**OFF**

HMU base law = reversion.

**TORQUE Ind**

White TQ bug manually selected.

Knob enables setting of white TQ bug.

**LIMITS**

From 0 to 137% (42)/0 to 109.5% (72).

Actual TQ display.

Dashes ( - - - ) for an Handling Bleed Valve failure (anti surging system of the engine)

**TEST**

115% (blue dot)

**ALERT Lt**

> 800°C (or > 715°C on ENG2 in hotel mode). CAP.

**TEST**

1150° (blue dot)

**NH-NL Ind**

(DC ESS)

Thin pointer: NL (104.2% max)

Wide pointer and digital display: NH (102.7% mar)

**TEST**

115% (blue dot)

**FUEL FLOW Ind**


(DC BUS 1/2)

**FU reset knob**

FU reset to 0 when pulled.

**FUEL USED Readout**

(DC BUS 1/2)



## UNLOCK

gear not locked in handle selected position (on ground, up lock box not open)

## Green Lt

gear downlock engaged

Green Hyd Press Ind.

BRK ACCU Press in blue system  
For Emer brakes max.  
6 applications. DC STBY  
Blue Hyd Press Ind

## ANTISKID

Operational if speed >10kts.  
Activates when Spd >23kts  
+50% diff between wheels.  
Braking action inhibited at  
touchdown as long as wheel  
spin ud spd <35 kts or for  
5 sec

## FAULT

wheel channel failure. CAP

## OFF

Pb released, system  
desactivated

## TEST pb

inhibited if speed > 17 kts  
MC + SC + CAP + 4F amber  
Lt

Test duration:  
3 sec in flight  
6 sec on ground

## CAUTION: THE TEST INHIBITS BRAKES!

## HOT

Any brake >160°C (42).  
>150° (72). CAP

## LO-SPD

ON <190 kts(42), 180 kts(72)  
= TLU released allow full  
rudder travel  
OFF >195 kts (42), 185 kts (72)  
Not ON <190 kts (42),  
180 kts (72) = maximum  
Xwind 15 kts.

## FAULT

stick shaker or pusher failure.

## OFF

turns off both shaker and pusher

## ROLL

shows LH aileron trim  
controlled tab travel.  
All Motor pwr = DC EMER

## YAW

shows units of trim motor  
displacement

## PITCH

shows right trim actuator  
controlled tab travel. If not in  
green arc at TO, CONFIG in  
CAP

## Gear position sensed by system I (MFC 1A)



## Gear handle red Lt

any gear not sensed down  
and locked with the further  
conditions

a) Any gear not down and  
locked + flaps  
normal landing configuration  
+ Zra <500 ft + PL at low  
power (impossible to cancel)  
b) Any gear not down and  
locked +1 PL at low power  
+ Zra < 500 ft and 150 sec  
after gear retraction (can be  
cancelled).

**NOTE:** Any gear not down must  
be sensed by each MFCs

## OFF FLAG

loss elec power

**Cabin alt:** based on 29.92  
(1013,2 Hpa)

**Cabin rate of climb**

**DIFF. Press**  
max +6.35/-0,5

## EXT (BLUE)

flap hyd. valve commanding  
flap extension is opened.  
If EXT appears when flaps are  
extended = hyd circuit leak

## FLAP ASYM

> 6.7° CAP. Flaps frozen in  
actual position

## PITCH TRIM ASYM

pitch tab desynchronization.  
CAP

## AUTO PRESS (DC BUS 1)

+550 up to FL 200  
+620 above FL 200

Memorize departure field  
elev up to 3500 ft

## ELV SET

Select switch to set landing  
elevation

## FAST

descent rate increased from  
-400 to -500 ft/mn  
To be used if VS>-1500 fpm

## TEST

displays alternatively 18800  
and -8800, FAULT appears  
on MAN pb  
(Test inhibited in FLT)

## DUMP

**ON (guarded)**  
both outflow valves fully open  
in AUTO mode only

## NORM

AUTO mode selection

## MAN

digital controller out of  
operation. No more digits in  
landing elevation display

## FAULT

digital controller failure. CAP

## ON

both outflow valves  
forced to be fully closed

## DE ICING Lt

a) Illuminates when airframe  
deicing syst is ON.  
b) Flashes when airframe  
deicing syst still selected ON  
5 min after last ice accretion  
detection

**Weather radar control panel**

Control the weather radar but the EGPWS too (for the power supply and the range)  
If OFF, the GPWS is triggered on CAP

**CAPT EFIS CONTROL PANEL**

**MCDU (Multifunction Control Display Unit)**

Access to the GNSS, MPC and ACARS (Data Link)  
When ACARS is installed, the aircraft is fitted with 2 MCDU

**F/O EFIS CONTROL PANEL**

**COCKPIT DOOR CONTROL PANEL**

**TO CONFIG TEST pb:**

Check if the TO configuration is correct for take off:  
- PWR MGT TO  
- Flaps 15°  
- Pitch trim in the green band  
- TLU LO SPD  
- no AIL LOCK light  
The same test is performed when advancing the PL with this additional requirement:  
- Parking Brake released

**Gust lock**

**AIL LOCK** triggered whenever one of the locking actuators is in disagreement with the gust lock lever position (lock or unlock position)

**POWER LEVER ( PL )**

**GA push button**

when depressed the GA FD mode is selected with:  
- **HDG HOLD** lateral mode with the wings level  
- **GA** vertical mode

**HYD AUX PUMP CONTROL (HOT MAIN BAT BUS)**

- Aux pump stopped 30" after p/b released (MFC supplied)  
- Aux pump stopped after p/b released (MFC not supplied)

**IDLE GATE**

**IDLE GATE FAIL**  
activated when the gate does not engage automatically in flight or does not extend automatically on ground

In this case the idle gate lever enables manual override in case of failure of the automatic logic  
- In flight: push  
- On ground pull (an amber band appears)

**EMER & PARKING BRAKE**

**CONDITION LEVER ( CL )**

**FLAPS**

**EMER AUDIO CANCEL**

This SW cancel an undue aural alert.  
Cancelled aural warning will be reactivated:  
- at next A/C energization  
- after MFC 1B/2B reset  
- after pressing RCL pb  
The alert here after are rearmed as soon as the triggering condition disappears  
- landing gear  
- VMO, VFE, VLE  
- Stall warning  
- Pitch trim whooler  
- AP disconnect

- ADF 2
- VHF 2
- ATC 1/2

**F/O AUDIO CONTROL PANEL**

Manual recording on DFDR or CVR (when supplied by GPU)  
Manual recording stopped with the reset P/B

- VHF1
- ADF1

**CAPT AUDIO CONTROL PANEL**

**Panel & flood light control**

**TCAS control panel**

MPC option without FDEP

**FDEP (Flight Data Entry Panel)**

Can not be fitted on aircraft equipped with the MPC. In that condition the flight number has to be entered through the MCDU

**Aileron, rudder & stby pitch trims**

**ATPCS test (static or dynamic)**

**STATUS Light**

**STATUS FDAU** light  
Illuminates amber when the FDAU is failed  
**STATUS SYST** light  
Illuminates amber when DFDR fail or the DFDR electrical supply is lost

## EGPWS (or TAWS if T2CAS equipped)

### GPWS switch and associated lights:

- ON:** All basic GPWS modes are operative
- FLAP OVRD:** In reduced flap landing, to inhibit the mode 4 alert
- OFF:** All basic GPWS modes inhibited.
- OFF:** light come on
- FAULT:** GPWS FAULT → some or all GPWS basic modes are lost
- FAULT:** TERR FAULT → some or all enhanced modes are lost
- OFF:** All enhanced (TCF&TAD) modes inhibited

## STICK PUSHER

Illuminates when stick pusher is operating

## AP OFF

Both lights illuminate or flash red when autopilot associated to the cavalry charge aural alert

## GUIDANCE

in CAT II, when an Excess deviation is detected

## GPWS


If any mode 1-2-3-4-TCF-TAD alert of the EGPWS (or TAWS) is activated  
G/S: If mode 5 is activated

## SWITCHING PANEL

When facing to a failure on the Attitude/ heading or VOR/ILS or SGO, it permits to recover the information from the other side. Priority is always given to the captain

## MKR

Allows selection of marker sensitivity (LO or HI)



## AUDIO 1/ 2 SEL

**FAULT:** When the associated RCAU part is failed.  
**ALTN:** Affected crew station is connected directly to:  
– VHF1 if CAPT station is affected.  
– VHF2 if F/O station is affected.

## A/ERECT FAIL

Associated AHRS loses the TAS signal from the ADC. The AHRS is operating in basic attitude mode. Aircraft stabilized, gyro fast erection when pushing on the P/B for 15s

## DSP SEL P/B

**RDR:** Weather Radar display on EFIS  
**TERR:** Terrain display on EFIS  
Even if RDR is selected, in case of terrain warning an automatic pop out permit to have the terrain display on EFIS

## ADC SWITCH

To feed either from ADC1 or ADC2  
– EEC1/2  
– TAT/SAT/TAS indicator  
– GNSS  
– FDAU  
**FAULT:** some or all the systems here above, are fed by the ADC 1 when the ADC 2 is selected (relays defect)  
Never faulty if selected to ADC 1

**MASTER WARNING  
MASTER CAUTION**

**APM alert lights:**

**CRUISE SPEED LOW**

cruise only. An abnormal drag increase induces a speed decrease >10kt

**DEGRADED PERF**

cruise and climb. An abnormal drag increase induces a speed decrease or a loss of rate of climb

**INCREASE SPEED**

After degraded perf. Drag abnormally high and IAS lower than RED BUG + 10 kt

**APM Weight rotary selector**

Before take off (Both engines running), it should be set to minimum weight then to take off nearest weight. Only taken into account if the selector has been changed. No effect for any change in flight.


If no selection, an internal calculation computed at the beginning of the flight, is used.

**APM FAULT**

Failure in the APM function computation

**APM Test PTT**

performed daily



**LOUDSPEAKERS  
VOLUME KNOBS**

Individual knob for each loudspeaker

72-212A

SPEED LIMITS (IAS)	
VMO/MMO:	250Kt/0.55
VA:	160Kt
VLE:	180Kt
VLO: LOWERING	170Kt
RETRACTING	160Kt
VFE:	
-TO (15°)APP:	180Kt
-APP (25°):	160Kt
-LDG (35°):	150Kt

42-500

**CONSOLE LT knob**

Control the lights of the associated lateral console

**READING LT knob**

Control the respective spot light

## LATERAL MODE

- VOR** ARMED MODE
- VOR\*** CAPTURED MODE
- VOR** TRACKED MODE

## VERTICAL MODE

- ALT** ARMED MODE
- ALT\*** CAPTURED MODE
- ALT** TRACKED MODE



ALT knob controls the preselected altitude on ADU

FD bars SW to set ON/OFF

NAV 1

NAV 2

**CRS 1** knob selects Course on CAPT EHSI

**Pitch wheel** to adjust  
 - VS or  
 - IAS or  
 - Pitch attitude in basic mode

**CRS 2** knob selects Course on F/O EHSI

**STBY COMPASS**  
 Hidden in up position. Compass Control should be place on DN For use. The compass rose is graduated in 10 degrees increments

**HDG** knob selects **HDG bug** on both EHSI


- **AP** pb engages autopilot and yaw damper and disengages only autopilot
- **YD** pb engages yaw damper and disengages yaw damper and autopilot if engaged
- **CPL** pb permit to couple AP/FD On CAPT or F/O side  
 In **CAT 2** (ILS selected on NAV 1&2)
  - 1200 ft RA: Dual coupling < >
  - 800 ft RA: CAT 2 invalid if still in single coupling
  - 500 ft RA: ILS excess dev activated
  - 100 ft RA: GS excess dev deactivated

**N/W STEERING**

**ON:** The steering solenoid valve is electrically armed. The steering is available with an angle up to 60° in either direction  
**OFF:** The steering system is unpressurized. Should be OFF for towing and push back  
 The steering is disconnected with an angle up to 91° in either direction

**Nose wheel steering Push To Talk**

When depressed, BOOM SET or OXY mike is connected for transmission over the selected communication facility



**Position of the selector:**

**EXT PWR**

DC panel indicates the DC GPU voltage & current  
 AC panel indicates the AC GPU voltage, load & current

**GEN 1/ 2**

DC panel indicates the DC Generator voltage & current  
 AC panel indicates the ACW Generator voltage, load & current

**INV 1/ 2**

No indication on DC panel  
 AC panel indicates the AC Inverter voltage, load & current

**MAIN and EMER BAT**

DC panel indicates the DC Main & Emer Battery voltage & current  
 No indication on AC panel

**PRELIMINARY COCKPIT PREPARATION: OXYGEN MASK TEST**

INT/RAD SELECTOR (On AUDIO CONTROL PA ..... SET TO INT  
 PRESS TO TEST AND RESET PB ..... DEPRESS AND HOLD

**NOTE:** Hose and mask charged with oxygen. Observe blinker momentarily turns yellow and must turn dark if there is no leak

PRESS TO TEST AND RESET PB ..... HOLD  
 RED GRIPS ON EACH SIDE OF THE HOSE ..... PRESS

**NOTE:** Oxygen pressure inflates the harness. Observe blinker momentarily turns yellow and must turn dark

PRESS TO TEST AND RESET PB ..... HOLD  
 EMERGENCY KNOB ..... SELECT

**NOTE:** Emergency flow is tested. Observe blinker momentarily turns yellow during oxygen flow and must turn dark when the knob is released.

**NOTE:** In this 3 cases, check that oxygen flow sounds though loudspeakers


OXY LO PR LIGHT ..... CHECK EXTINGUISHED  
 N/100% Selector ..... SET to 100%

## FLIGHT DECK VENTILATION ISOLATION EXTRACT AIR FLOW

**CAUTION:** Close only in case of FWD COMPT smoke  
Enables, in case of smoke in the forward cargo compartment, to isolate the flight deck ventilation preventing smoke to enter the flight compartment

## MAIN PNL

Before the flight, check that all the switch and selector are in the normal position.  
If not, the MAINT PNL is illuminated on the CAP



**BITE LOADED magnetic indicator**  
Indicates that a failure has been recorded by the maintenance system.  
Report to maintenance

**BRK TEMP TEST**  
When depressed, MC, SC, WHEEL on CAP and HOT amber light illuminates

## Annex 2. Abbreviations

### A

AAS	Anti-icing Advisory System
AC	Alternating Current
ACARS	ARINC Communication Addressing and Reporting System
AC BTC	AC Bus Tie Contactor
AC BTR	AC Bus Tie Relay
ACW	Alternating Current Wild Frequency
ADC	Air Data Computer
ADF	Automatic Direction Finding
ADI	Attitude Director Indicator
ADS	Air Data System
ADU	Advisory Display Unit
A/EREC	Auto Erection
AFCS	Automatic Flight Control System
A/FEATH	Auto Feathering
AFT	Rear Part
AFU	Auto Feather Unit
AGB	Accessory Gear Box
AHRS	Attitude and Heading Reference System
AHRU	Attitude and Heading Reference Unit
AIL	Aileron
ALT	Altitude
ALTM	Altimeter
ALTN	Alternate
AMP	Ampere
AOA	Angle of Attack
AP	Auto-Pilot
APP	Approach
APU	Auxiliary Power Unit
ARM	Armed
ASCB	Avionics Standard Communication Bus
ASI	Air Speed indicator
ASYM	Asymmetry
ATC	Air Traffic Control
ATPCS	Automatic Take off Power Control System
ATT	Attitude
ATTND	Attendant
AUTO	Automatic
AUX	Auxiliary
AVAIL	Available

### B

BARO	Barometric
BAT	Battery
BC	Back Course
BITE	Built in Test Equipment
BPCU	Bus Power Control Unit
BPU	Battery Protection Unit
BRG	Bearing
BRK	Brake
B-RNAV	Basic Area Navigation

BRT	Bright
BTC	Bus Tie Contactor
BTR	Bus Tie Relay

### C

CAB	Cabin
CAP	Crew Alerting Panel
CAPT	Captain
CAT	Category
C/B	Circuit Breaker
CCAS	Centralized Crew Alerting System
CDI	Course Deviation Indicator
CHAN	Channel
CHC	Charge Contactor
CL	Condition Lever
CLA	Condition Lever Angle
CLB	Climb
CLR	Clear
CMPTR	Computer
COM	Communication
COMPT	Compartment
CONFIG	Configuration
CPL	Auto Pilot Coupling
CRC	Continuous Repetitive Chime
CRS	Course
CRT	Cathodic Ray Tube
CRZ	Cruise
CTL	Control
CVR	Cockpit Voice Recorder

### D

DADC	Digital Air Data Computer
DC	Direct Current
DELTA P	Differential Pressure
DEV	Deviation
DFDR	Digital Flight Data Recorder
DGR	Degraded
DH	Decision Height
DIFF	Differential
DISCH	Discharge
DIM	Light Dimmer
DIST	Distance
DME	Distance Measuring Equipment
DN	Down
DSPL	Display

### E

EADI	Electronic Attitude Director Indicator
ECU	Electronic Control Unit
EEC	Engine Electronic Control
EFIS	Electronic Flight Instrument System
EHSI	Electronic Horizontal Situation Indicator
EHV	Electro Hydraulic Valve
ELEC	Electrical

ELV	Elevation
EMER	Emergency
ENG	Engine
EQPT	Equipment
ESS	Essential
ETOPS	Extended Twin Operations
EXT	Exterior, External
<b>F</b>	
F	Fahrenheit
FAIL	Failed, Failure
FCOC	Fuel Cooled Oil Cooler
FD	Flight Director
FDAU	Flight Data Acquisition Unit
FDEP	Flight Data Entry Panel
FEATH, FTR	Feathered, Feathering
FF	Fuel Flow
FGC	Flight Guidance Computer
FGS	Flight Guidance System
FI	Flight Idle
FLT	Flight
FMA	Flight Modes Annunciators
FMS	Flight Monitoring System
F/O	First Officer
FOS	Flight Operations Software
FQI	Fuel Quantity Indication
FT	Foot, Feet
FU	Fuel Used
FWD	Forward
<b>G</b>	
GA	Go Around
GCU	Generator Control Unit
GEN	Generator
GI	Ground Idle
GND	Ground
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
GPU	Ground Power Unit
(E)GPWS	(Enhanced) Ground Proximity Warning System
GRD	Ground
G/S	Glide Slope
GSPD	Ground Speed
<b>H</b>	
HBV	Handling Bleed Valve
HDG	Heading
HF	High Frequency
HI	High
HLD	Hold
HMU	Hydromechanical Unit
HP	High Pressure
HSI	Horizontal Situation Indicator
HTG	Heating
HYD	Hydraulic
<b>I</b>	
IAS	Indicated Air Speed
IDT	Ident

IGN	Ignition
ILS	Instrument Landing System
IND	Indicator
IN/HG	Inches of Mercury
INHI	Inhibit
INOP	Inoperative
INST	Instrument
INT	Interphone
INV	Inverter
ISOL	Isolation
ITT	Inter Turbine Temperature

## JK

KHZ	Kilo-Hertz
KT	Knot

## L

LAT	Lateral
LAV	Lavatory
LB	Pound
LDG	Landing
L/G	Landing Gear
LH	Left Hand
LNAV	Lateral Navigation
LO	Low
LOC	Localizer
LO-PR	Low Pressure
LP	Low Pressure
LT	Light
LVL	Level

## M

MAX	Maximum
MB	Millibar
MC	Master Caution
MCDU	Multifunction Control Display Unit
MCT	Maximum Continuous
MECH	Mechanic
MFC	Multi Function Computer
MFCU	Mechanical Fuel Control Unit
MGT	Management
MHZ	Megahertz
MIC	Microphone
MIN	Minimum
MISC	Miscellaneous
MKR	Marker
MLW	Maximum Landing Weight
MM	Millimeter
MMO	Maximum Operating Mach
MOD	Modification
MSG	Messages
MSN	Manufacturer Serial Number
MTOW	Maximum take off Weight
MW	Master Warning
MZFW	Maximum Zero Fuel Weight

## N

NAC	Nacelle
NAV	Navigation
NDB	Non Directional Beacon

NEG	Negative
NH	High Pressure Spool Rotation Speed
NIL	Nothing, No Object
NL	Low Pressure Spool Rotation Speed
NM	Nautical Mile
NORM	Normal
NP	Propeller Rotation Speed
NPU	Navigation Processor Unit
N/W	Nose Wheel
NWS	Nose Wheel Steering

**O**

OAT	Outside Air Temperature
OBS	Omni Bearing Selector
OVBD	Overboard
OVERTEMP	Overtemperature
OVHT	Overheat
OVRD	Override
OXY	Oxygen

**P**

PA	Passenger Address
PB	Push Button
PEC	Propeller Electronic Control
PIU	Propeller Interface Unit
PL	Power Lever
PLA	Power Lever Angle
PNL	Panel
POS	Position
P-RNAV	Precision Area Navigation
PRESS	Pressurization, Pressure
PRIM	Primary
PRKG	Parking
PROP	Propeller
PSI	Pound per Square Inch
PSU	Pax Service Unit
PT	Point
PT (TCAS)	Proximity traffic
PTT	Push To Talk, Push To Test
PTW	Pitch Thumb Wheel
PVM	Propeller Valve Module
PWR	Power

**Q**

QAR	Quick Access Recorder
QT	Quart
QTY	Quantity

**R**

RA (TCAS)	Resolution Advisory
RA	Radio Altitude
RAD/ALT	Radio Altitude
RAD/INT	Radio/Interphone
RCAU	Remote Control Audio Unit
RCDR	Recorder
RCL	Recall
RCU	Releasable Centering Unit
RECIRC	Recirculation
REV	Reverse

RGA	Reserve Go-Around
RGB	Reduction Gear Box
RH	Right Hand
RLY	Relay
RMI	Radio Magnetic Indicator
RNP	Required Navigation Performance
RPM	Revolution Per Minute
RTO	Reserve Take-Off
RUD	Rudder

**S**

SAT	Static Air Temperature
SBY	Stand By
SC	Single Chime, Starter Contactor
SEL	Selector
SGL	Single
SGU	Symbol Generator Unit
SMK	Smoke
SMKG	Smoking
S/O (SO)	Shut Off
SOV	Shut Off Valve
SPD	Speed
SPLR	Spoiler
SPLY	Supply
STBY	Stand By
STRG	Steering
SVCE	Service
SW	Switch
SYS	System

**T**

TA (TCAS)	TRAFFIC Advisory
TAD	Terrain Awareness Display
TAS	True Air Speed
TAT	Total Air Temperature
TAWS	Terrain Awareness Warning System
TCF	Terrain Clearance Floor
TCS	Touch Control Steering
TEMP	Temperature
TGT	Target
TK	Tank
TLU	Travel Limiting Unit
T/O (TO)	Take off
TOW	Take off weight
TQ	Torque
TRU	Transformer Rectifier Unit
TTG	Time To Go

**U**

U/F	Underfloor
UHF	Ultra High Frequency
UNCPL	Uncouple
UNDV	Undervoltage
UNLK	Unlock
UTLY	Utility

**V**

VC	Calibrated Airspeed
VENT	Ventilation

VERT  
VHF  
VMO  
VNAV  
VOR  
VSI

## W

WARN  
WOW  
XFEED  
XFR

Vertical  
Very High Frequency  
Maximum Operating Speed  
Vertical Navigation  
VHF OMNI Directional Range  
Vertical Speed Indicator

Warning  
Weight On Wheel  
Cross feed  
Transfer

## XY

YD

Yaw Damper

## Z

ZA  
ZCTH  
ZFW  
ZP  
ZRA

Aircraft Altitude  
Theoretical Cabin Altitude  
Zero Fuel Weight  
Pressure Altitude  
Radio Altimeter Altitude



Dear Readers,

Every effort has been made to ensure document quality.  
However please do not hesitate to share your comments and information  
with us by using the following address: [flight-ops-support@atr.fr](mailto:flight-ops-support@atr.fr)

Yours faithfully,

Your ATR Training and Flight Operations support team.



Printed on 100% recycled paper using vegetable inks